



Russell Hobbs



instructions, troubleshooting guide, and guarantee


Problems?

Don't take it back to the shop,
they won't be able to fix it.

Ring the helpline

0845 658 9700

it's a local rate number



Read the instructions before using your vacuum cleaner, and keep them safe.

If you pass the cleaner on, pass on the instructions too.

important safeguards

Follow basic safety precautions, including the ones below. It's quite a list, but most of them are simple common sense.

- 1 The cleaner should only be used by or under the supervision of a responsible adult. It's not a toy – don't let children play with it.
- 2 Don't put the cleaner in any liquid, and don't use it anywhere damp or wet.
- 3 Don't use the cleaner near a gas, oil (including paraffin), or open fire. The flame may be sucked towards the cleaner, causing a fire hazard.
- 4 Keep hair, clothing, fingers (and toes), away from the end doing the sucking, and from the brush. It won't drag you into the bin, but it may give you a bit of a start.
- 5 Stuff you mustn't pick up:
 - a) don't pick up any liquid – you'll short the motor
 - b) don't pick up stuff that may ignite spontaneously, like matches, bits of fire-lighter
 - c) don't pick up anything burning or smouldering, like cigarette ends, ashes, or embers – wait till they're extinguished and cold
 - d) don't pick up spillage from toner cartridges – the fine carbon particles may pass through the filter, short circuit the motor, and burn it out
 - e) don't pick up cement or plaster dust – they'll combine with moisture in the air, clog the filter, scour the bin, and maybe burn out the motor too
 - f) don't pick up anything sharp – you may puncture the filter and damage the motor
 - g) don't pick up anything biological – you'll eventually have to clean it off the filter, and there's always the possibility that viral particles may pass through the filter, reach the air outlet, and enter your air supply
- 6 If you use the cleaner outdoors (e.g. cleaning the car), connect it to the electricity supply via a residual current device (RCD), with a rated residual operating current not exceeding 30mA. Don't let the cleaner get wet.
- 7 Don't leave it unattended when plugged in.
- 8 Keep an eye on the cable, so it doesn't catch on anything, or trip anyone up. Don't run the cleaner over the cable, you'll damage it.
- 9 If you're using the cleaner on stairs, sit it where it can't topple, and keep it below you, so if it does topple, it won't land on you.
- 10 Don't use the cleaner on people, animals, birds, or pets.
- 11 Unplug the cleaner and rewind the cable when not in use, before moving and before cleaning.
- 12 Don't use the cleaner if the bin is full – switch off, unplug, and empty it.
- 13 Don't use the cleaner for any purpose other than those described in these instructions.
- 14 Don't use accessories or attachments other than those we provide.
- 15 Don't leave the cleaner in sunlight, prolonged exposure to UV may damage plastics.
- 16 Don't use the cleaner if it's damaged or malfunctions.
- 17 If the cable or plug is damaged, return the cleaner, to avoid hazard.



household use only

before using for the first time

Remove all packaging, but keep it in case you ever need to return the cleaner.

count the bits

In the box you'll find an extendable tube, a big brush, a crevice tool, a small brush, a sofa brush, and a hose (with nozzle). They may be packed separately, so check all of the packaging before you dispose of it.

filters

Keep the filters clean – if they get blocked, you'll lose suction rapidly.

fitting the hose

- 1 Push the hose end into the inlet. You'll hear a click as it locks into position.
- 2 Give it a gentle tug to check it's fitted properly.

cable

- 3 Pull as much cable as you need from the back of the cleaner.
- 4 The yellow band round the cable tells you there's about a metre left.
- 5 The red band about half a metre later tells you "Stop pulling, you've run out of cable!".
- 6 Keep an eye on the cable so it doesn't catch on anything, or trip anyone (including you).

carrying and moving the cleaner

- 7 Lift the cleaner only by the carrying handle.
- 8 When the cleaner is sitting on its wheels (normal position), you can move it around by pulling gently (that's gently), on the hose.
- 9 For stationary jobs like curtains, you may sit the cleaner up, with the handle at the top, but don't try to move it like this, or it'll fall over.



choose the tool for the job

- 10 The tools will fit on the nozzle, or on the narrow end of the extendable tube.
- 11 You'll have your own preferences, but here are a few tips for the first time user.
 - big brush** normally used with the extendable tube, for floors and carpets:
Press the rear of the brush pedal to extend the bristles for floor coverings with little or no pile.
Press the front of the brush pedal to retract the bristles for use on rugs, carpets, and anything with pile.
 - crevice tool** as the name implies, down the sides of upholstery, in awkward spaces, nooks, and crannies nothing else can reach.
 - small brush** use it to remove pet hair, lint, and dust from blinds, and curtains, and to brush/clean awkward corners.
 - sofa brush** use this to remove pet hair, lint, and dust from upholstery, and other small, flat areas – don't use it on hanging curtains, as it doesn't have the bristles necessary to let air flow freely, use the small brush instead.

tubes

- 12 Fit the extendable tube to the nozzle for floors, carpets, or hard to reach places:
 - a) push the tube release towards the narrow end of the tube, and keep it pressed
 - b) pull out as much of the inner tube as you need – if you're done, push it back
 - c) return the tube release to the locked position
- 13 Push the wide end of the extendable tube on to the nozzle.
- 14 Choose a tool, and push it onto the narrow end of the tube.

suction control

- 15 There are two ways to control the suction:
 - a) The suction control on the top rear of the cleaner – slide it towards max to increase the cleaning power, towards min to decrease the power.
 - b) The suction control on the nozzle – move it towards the nozzle for maximum suction, away from the nozzle, to reduce suction.

plug in

caution If you've accidentally pressed the on/off switch ①, the cleaner will work when you plug it in. This could give you a bit of a start, so be careful.

- 16 Plug the cable into a socket near the area to be cleaned (if it's a switched socket, switch it on).

switching on

17 Press and release the on/off switch ①, to turn the cleaner on.

cleaning

18 Move the tool over the surface, cleaning a small area at a time.

19 When you move to a new area, overlap the previous area, to make sure none of the surface is missed.

switching off

20 If you've finished, if you want to change tools, or if you just want to stop for a rest, press and release the on/off switch ①, to turn the cleaner off.

finished cleaning?

21 Press and release the on/off switch ①, to turn the cleaner off.

22 Unplug the cleaner (switch the socket off first, if it's switchable).

23 Stand clear of the cable, and press the Ⓢ button – the cable will rewind.

24 Keep clear of the cable, as it rewinds at a fair lick. If it catches on anything, stop pressing, and it'll stop rewinding.

25 We've tried not to make it too powerful, to avoid wrecking your home, so you may need to push the plug end into the storage area manually.

removing and emptying the bin

26 You don't have to empty the bin after each use, but it's a very good idea. Your cleaner will happily work till it's chock full, but you'll be wasting energy swirling yesterday's dust around. Energy that could be better used sucking up today's dust.

27 There's a "bin full light" on top of the cleaner, behind the suction control.

28 If it lights, the bin is full – you should empty it right away.

29 Switch off, unplug, set it down on its wheels, and leave it for a minute, to let the dust settle.

30 Squeeze the locks on the hose end, and pull the hose out of the inlet (removing the hose isn't essential, but it makes life so much easier).

31 Squeeze the latch on the front of the cleaner into the cleaner, and open the cover.

32 Raise the handle on top of the bin, and lift the bin out of the cleaner.

33 Ease the bottom of the bin lock away from the catch, and rotate the bin lid backwards, on its hinges, till it comes free of the bin.

34 Lower the bin into your dustbin, then turn it upside down to empty it.

35 Tap the side of the bin, to shake all the dirt loose.

★ if you want to check the filters, jump to point 42, otherwise carry on.

36 Locate the rear of the bin lid on the hinges at the rear of the bin.

37 Rotate it forwards, till the bin lock is secured over the catch on the front of the bin.

38 Lower the bin into the cleaner, then push it gently back, towards the rear of the cleaner, to lock it into place.

39 Lower the bin handle on top of the bin lid.

40 Close the cleaner – you'll hear the latch click into place.

41 Push the hose end into the inlet. You'll hear a click as it locks into position.

checking the filters

42 When you've emptied the bin, check the filters. Blocked filters quickly reduce suction, and they're easy to clean.

precautions

43 Spread out some newspaper – you're likely to make a mess.

44 Wearing rubber gloves is a good idea – they'll protect your fingers from anything nasty that's reached the filters.

remove the main filter

45 This filters the returning airflow.

46 It's a HEPA filter, it's expensive to replace, so be gentle with it. With careful handling, it should last for years.

47 it's fitted into the bottom of the bin.

48 Hold the bin in one hand, squeeze the catches on the front and rear of the main filter, and pull it down and out of the bin.

49 Lift the foam out of the main filter.

50 Wash the foam in warm soapy water, rinse it thoroughly, squeeze it out, and leave it to air dry.

✳ Check that the foam is completely dry before replacing it on the main filter.

51 Tap the main filter gently over the newspaper, to dislodge any dirt.

52 If it's really dirty, soak it in warm soapy water for a few minutes, rinse under a running tap, to remove all trace of soap, then let it air dry.

✳ Check that the main filter is completely dry before replacing it in the cleaner.

53 Replace the foam in the top of the main filter – it's a funny shape, so it'll only fit one way round.

plastic filter

54 This is mounted inside the bin – it's not removable.

55 While the main filter is out of the bin, you can reach both the outside and the inside of the plastic filter.

56 Tap it over the newspaper, to dislodge any dirt.

57 Anything stubborn can be brushed off (an old toothbrush is ideal for this).

replace the main filter

58 Push the main filter up into the bottom of the bin, till you hear the catches click into place.

59 Locate the rear of the bin lid on the hinges at the rear of the bin.

60 Rotate it forwards, till the bin lock is secured over the catch on the front of the bin.

61 Don't put the bin back into the cleaner.

motor guard

62 You'll find the motor guard at the rear of the space occupied by the bin.

63 Slide it up and out of its retaining slots.

64 Pull the fibre filter out of the motor guard.

65 Tap it gently over the newspaper, to dislodge any dirt.

66 If it's really dirty, soak it in warm soapy water for a few minutes, rinse under a running tap, to remove all trace of soap, then let it air dry.

✳ Check that the fibre filter is completely dry before replacing it in the cleaner.

67 Push it back into the rear of the motor guard.

68 Align the tabs on the sides of the motor guard with the slots at the rear of the bin compartment, and slide the motor guard back into place – the finger grip must be at the top.

replace the bin

69 Lower the bin into the cleaner, then push it gently back, towards the rear of the cleaner, to lock it into place.

70 Lower the bin handle on top of the bin lid.

outlet filter

71 Lift the outlet filter out of the top of the cleaner – it's a HEPA filter too, so be gentle with it.

72 Tap the filter gently over the newspaper, to dislodge any dirt.

73 If it's really dirty, soak it in warm soapy water for a few minutes, rinse under a running tap, to remove all trace of soap, then let it air dry.

✳ Check that the outlet filter is completely dry before replacing it in the cleaner.

74 Lower it into the outlet on top of the cleaner.

close the cleaner

75 Close the cleaner – you'll hear the latch click into place.

76 Push the hose end into the inlet. You'll hear a click as it locks into position.

cleaning the cleaner

77 Switch the cleaner off and unplug it before cleaning.

78 Don't put any part of the cleaner in a dishwasher.

79 Don't use harsh or abrasive cleaning agents or solvents.

80 Wipe external surfaces of the cleaner with a damp cloth.

81 Wipe the tools and tubes with a damp cloth.

82 A dab of washing-up liquid will remove stubborn stains, but clean it off afterwards, or it may stain.

timing

83 Clean the cleaner frequently. Basically, the better you look after it, the longer it'll last. Keep an eye on it as you use it, and examine the filters when you empty the bin. If anything needs cleaning, do it there and then, don't put it off, in case you forget.

blockages

84 No matter how careful you are, sooner or later you'll block the cleaner.

don't panic!

If the cleaner starts to get noisy and you start to lose suction, don't worry, it's not the end of the world, you've probably just blocked it up.

1 Switch the cleaner off and unplug it.

2 Spread a newspaper on the floor, you're going to make a mess.

3 If you're using one of the tools, remove and check it first.

4 Remove the hose and check it.

5 Use something blunt, like the blunt end of a ball-point pen to dislodge any blockage.

6 The plastic filter is the cleaner's first line of defence, so it's likely to be the first one to block up, if you're using the cleaner to pick up anything dodgy.

7 You can see the top of the plastic filter through the side of the bin.

8 Remove the bin, and check the main filter and its foam protector.

9 The motor guard and outlet filter shouldn't cause a problem, but check them anyway, just in case.


10 If you haven't cleared the blockage by now, try again.

11 Still not clear? – Ring the helpline.

connection

The cleaner doesn't need an earth. It has a 13A BS1362 fuse in a 13A BS1363 plug. To replace the plug, fit the blue wire to N, and the brown wire to L. Fit the cord grip. If in doubt, call an electrician.

Don't use a non-rewireable/moulded plug unless the fuse cover is in place. If you remove the plug, dispose of it.



helpline – 0845 658 9700

If you need help, note the Model No (on the rating plate) and ring the helpline 0845 658 9700 (it's a local rate number).

service

If you ring Customer Service, please have the **Model No** to hand, as we won't be able to help you without it. It's on the rating plate (usually underneath the product).

The cleaner isn't user-serviceable. If it's not working, read the instructions, check the plug fuse and main fuse/circuit breaker.

If that doesn't solve the problem, don't take the cleaner back to the place you bought it – they won't be able to fix it. Ring Customer Service.

If they advise you to return the product to us, pack it carefully, include a note with your name, address, day phone number, and what's wrong. If under guarantee, say where and when purchased, and include proof of purchase (till receipt). Send it to:

Customer Service, Salton Europe Ltd, Failsworth, Manchester M35 0HS

email: service@saltoneurope.com

telephone: 0845 658 9700 (local rate number)

guarantee

Defects affecting product functionality appearing within one year of purchase will be corrected by replacement or repair provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. Documentation, packaging, and product specifications may change without notice.

wheelie bin symbol

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol mustn't be disposed of with unsorted municipal waste, but recovered, reused, or recycled.



online

www.russellhobbs.co.uk for more products

18068

550-557