# REMINGTON®

# **Amaze Smooth and Volume**





Redicted Old Filter Confident Confidence of the Confidence of the

Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

★ WARNING: This appliance is hot. Keep out of reach of children at all times.

## ♠ IMPORTANT SAFEGUARDS

- 1 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
- 2 Always ensure the voltage to be used corresponds to the voltage stated on the unit before plugging the appliance into the mains socket.
- 3 Warning: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- 4 When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the hairdryer is switched off.
- 5 For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
- 6 For UK, Household Use Only. Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the dryer/straightener is not permitted (see BS7671).
- 7 Do not wrap the cord around the unit. Check the cord regularly for any sign damage.
- 8 If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington\* service dealer for repair or replacement in order to avoid a hazard.
- 9 Do not use the appliance if it is damaged or malfunctions.
- 10 Do not allow any part of the appliance to touch the face, neck or scalp.
- 11 Keep direct airflow away from eyes or other sensitive areas.
- 12 During use, always ensure the inlet and outlet grilles are not blocked in any way as this will cause the unit to automatically stop. If this should occur, switch off and allow the unit to cool.
- 13 Ensure the inlet grille is free from obstructions such as fluff, loose hair etc.
- 14 Do not leave the appliance unattended while plugged in.
- 15 Do not set the appliance down while still on.
- 16 Do not place the appliance down on any soft furnishings.

- 17 Do not use attachments other than those we supply.
- 18 This appliance is not intended for commercial or salon use.
- 19 Let the appliance cool down before cleaning and storing away.



#### KEY FEATURES

- 1 1200W power handle
- 2 21mm thermal bristle brush
- 3 30mm retractable bristle curling brush
- 4 Root boost attachment
- 5 Paddle brush
- 6 Concentrator
- 7 Speed/heats setting switch
- 8 Attachment release switch
- 9 Storage case (not shown)
- 10 3m salon length swivel cord

#### PRODUCT FEATURES

- 1200 watts.
- Ceramic grille for even heat
- Ionic conditioning reduces static and frizz for healthy looking shine
- 3 heat/speed setting including cool air
- 5 attachments to create different styles
- Cool shot

# INSTRUCTIONS FOR USE

- 1 Wash and condition your hair as normal.
- 2 Squeeze out excess moisture with a towel and comb through.
- ★ Hairsprays contain flammable material do not use while using this product.
- 3 Select your attachment before you turn on the appliance.
- 4 Attachments can be connected to the power handle by simply aligning the arrows on the attachment and the handle and clicking into place.
- 5 Plug the product into the mains power supply.
- 6 To turn the product on slide the speed/heat setting switch to position '1'.
- 7 Dry roots completely and dry length 90% dry, ready for styling.
- 8 To dry hair use the concentrator attachment.
- 9 Section the hair prior to styling. Style the lower layers first.
- 10 Select the desired temperature and speed setting using the switch on the handle.
- 11 To increase the setting slide the heat/speed setting switch to position '2'.

#### ★ Root Boost Attachment

This is designed to create voluminous hair at the roots while it dries Push the
root boost slowly into your roots towards the centre of your head whilst
drying it. Allow the hair to push against the root boost. Lift the root boost
up pulling hair at a right angle to your head whilst drying. Repeat until you
have dry, voluminous hair.

#### ★ Paddle Brush Attachment

- This attachment is to create Salon straight hair. Simply brush through your hair slowly with the paddle brush, just like you would with a normal brush.
- ★ Tip You can add some volume and bounce if you tip your head upside down and do the underneath of your hair
- Then use your fingers to shape the hair and ends.

#### ★ Bristle Brush Attachments

- For all brush attachments: Take a section of hair and place the ends around the brush. Rotate the styler allowing the hair to wrap around the barrel of the brush drying and styling as you go.
- Use the 21mm thermal bristle brush for waves and smoother ends.
- Use the 30mm retractable bristle brush for firmer curls and waves.
- Let the hair cool before styling.
- Let the attachments cool before removing.
- To remove attachments, press the attachment release button and pull the attachment away from the main housing.
- After use, turn the appliance off and unplug.
- Let the appliance cool before cleaning and storing away.

#### ★ Cool shot

- To set your style and add shine use the cool shot function. To operate slide
  the heat/speed setting switch to position 'snowflake symbol'. Slide back to
  turn off.
- Let the attachments cool before removing.
- After use, turn the appliance off and unplug.
- Let the appliance cool before cleaning and storing away.

### CLEANING AND MAINTENANCE

- Unplug the appliance and allow to cool.
- To maintain peak product performance and to prolong motor life, it is important to regularly remove any dust and dirt from the air filter grille and clean with a soft brush.
- · Wipe all the surfaces with a damp cloth.
- Don't use harsh or abrasive cleaning agents or solvents.

# **ENVIRONMENTAL PROTECTION**

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol must not be disposed of with unsorted municipal waste, but recovered, reused or recycled.



#### **⇒** SERVICE AND GUARANTEE

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.

Your statutory rights are not affected.

Consumables are excluded.

Defects from repair by an unauthorized dealer are not covered.

If you call the Service Centre, please have the Model No. to hand, as we won't be able to help you without it. The Model No. can be found on the rating plate of the appliance.

Replacement parts and accessories are available to buy at www.remington.co.uk/parts-accessories

#### **⇒** SERVICE CENTRE

#### **United Kingdom**

Tel 0345 6460 438 (free call mainland UK)

+44 161 947 3111 (call outside the UK)

Spectrum Brands (UK) Ltd

Fir Street, Failsworth, Manchester M35 OHS, UK

www.remington.co.uk

#### Ireland

Tel 142 951 40

Remington Consumer Products, Unit B12, Ballymount Corporate Park, Ballymount, Dublin 12.

www.remington.co.uk

# 

£10,000 prize draw, EXTRA year guarantee, FREE rewards gallery.

Visit www.productregister.co.uk/remington. You must register within 28 days of purchase.

# Model No. AS1220

14/UK/ AS1220 T22-0002516 Version 07 /14

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries. Spectrum Brands (UK) Ltd

Fir Street.

Failsworth, Manchester

M35 0HS

www.remington.co.uk

© 2014 SBI