

REMINGTON®

PrecisionCut Hair Clipper



HC5900

Register online for
£10,000 prize draw
EXTRA year guarantee
FREE rewards gallery






Visit www.remington.co.uk/product/register
You must register within 28 days
of purchase.

Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

IMPORTANT SAFETY INSTRUCTIONS

WARNING – TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE OR INJURY TO PERSONS:

- 1 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
- 2 The adaptor contains a transformer. Do not cut off the adaptor to replace it with another plug, as this causes a hazardous situation.
- 3 Do not leave the appliance unattended while plugged in.
- 4 Keep the power plug and cord away from heated surfaces.
- 5 Make sure the power plug and cord do not get wet.
- 6 Do not plug or unplug the appliance with wet hands.
- 7 Do not use the product with a damaged cord. A replacement adaptor can be obtained via our International Service Centres.
- 8 Do not twist or kink the cable, or wrap it round the appliance.
- 9 Charge, use and store the product at a temperature between 10°C and 35°C.
- 10 This appliance is not intended for commercial or salon use.
- 11 Do not reach for an appliance that has fallen into water. Unplug it immediately.
- 12 Suitable for cleaning under an open water tap. 
- 13  This appliance should be supplied with approved safety isolating adaptors PA-4515E (for EU), PA-4515U (for UK) with the output capacity of 4.5Vdc; 1500mA (adaptor output).



KEY FEATURES

- | | |
|--|---------------------------------------|
| 1 On/Off/Turbo Switch | 5 LED fuel gauge |
| 2 Blade set | 6 Micro USB port |
| 3 2 attachment guide combs
1-21mm and 24-44mm (not shown) | 7 Adaptor (not shown) |
| 4 Blade release button | 8 Slide select adjustable comb switch |

GETTING STARTED

CHARGING YOUR APPLIANCE

- Before using your hairclipper for the first time, charge for 4 hours.
- Ensure the product is switched off.
- Connect the charging adaptor to the product and then to the mains.

- If the product is not going to be used for an extended period of time (2 – 3 months), unplug it from the mains and store.
- Fully recharge your hairclipper when you would like to use it again.
- Allow 4 hours for a complete charge.
- The clipper features a LED fuel gauge to show remaining charge and charging status, please see the tables below:

When connected to the mains and charging	
Battery: below 20% capacity	Red LED flash once per second
Battery: 20-40% capacity	Yellow LED flash once per second
Battery: 40-100% capacity	Blue LED flash once per second
Battery: 100% capacity	Blue LED will be solid

When using cordless	
Battery: 40-100% capacity	Blue LED will be illuminated
Battery: 20-40% capacity	Yellow LED will be illuminated
Battery: below 20% capacity	Red LED will be illuminated
Battery: below 5% capacity	Red LED will flash once per half second

When using cordless and Turbo is activated	
Battery: 40-100% capacity	Blue LED will illuminate once every 1.5 seconds
Battery: 20-40% capacity	Yellow LED will illuminate once every 1.5 seconds

Battery: below 20% capacity	Red LED will illuminate once every 1.5 seconds
Battery: below 5% capacity	No illumination will show

When used in corded mode	Blue LED will illuminate
When using corded in and Turbo is activated	Blue LED flash once per 1.5 seconds

- To preserve the life of your batteries, let them run out every 6 months then recharge for 4 hours.
- The clipper comes with a quick charge function, 10 minutes charging will give an emergency burst of run time.

✱ CHARGING VIA STANDARD ELECTRICAL SOCKET

- Ensure the product is switched off.
- Connect the charging adaptor to the product and then to the mains.

✱ USB

- Connect Micro USB to the appliance, and the USB connector to any standard USB port or charger
- Product will only charge through USB and will not run in corded mode.

✱ CORDED USE

- Connect the charging adaptor to the product then to the mains.

✱ CAUTION

- Extended mains only use will result in the reduction of the battery life.

✱ CORDLESS USE

- When the product is switched on and fully charged it can be used in cordless mode for up to 90 minutes.

⚠ INSTRUCTIONS FOR USE

✱ BEFORE STARTING THE CUT

- Inspect the clipper making sure that it is free from hair and dirt.

- Seat the person so that their head is approximately at your eye level.
- Before cutting, always comb the hair so it is tangle free and dry.

✱ TO ATTACH A COMB

- Hold the comb with its teeth upward.
- To attach a comb, align the legs of the comb with the holes in the top of the clipper on each side of the blade and slide the legs into the trimmer until the click.
- To remove, firmly pull the comb straight up away from the clipper.

✱ HAIR CLIPPER COMB SETTINGS

- The clipper comes with two adjustable combs, a short length adjustable comb (indicated by 1-21mm on the back of the comb) and a longer length adjustable comb (indicated by 24-44mm on the back of the comb).
- Please see table below for different cutting lengths available on each comb:

Shorter Length Adjustable Comb	Longer length Adjustable Comb
1mm	24mm
2mm	25mm
3mm	26mm
4mm	27mm
5mm	28mm
6mm	29mm
9mm	32mm
12mm	35mm
15mm	38mm
18mm	41mm
21mm	44mm

- On the slide select switch there is a silver indicator which, when the short length adjustable comb is on the product, shows the corresponding length setting on the left of the slide select switch. On the other side of the slide select switch there is another silver indicator which shows the corresponding

length setting when the longer length adjustable comb is on the product, on the right side of the slide select switch.

- To adjust the length settings, you must press the upper half of the slide select switch to release the locking mechanism, then apply force upwards on the slide select switch to increase the length setting. To decrease the length settings press the upper part of the slide select switch down and slide downwards.
- Use the clipper without any fixed combs for trimming hair close to the skin.
- This will trim hair to 1mm, holding the clipper so the blades are perpendicular to the skin will trim hair to 0.5mm.

✳ **INSTRUCTIONS FOR CUTTING HAIR**

- To turn the product On or Off press the On OFF button. To locate the On/Off button please refer to the key features section.
- For even cutting, allow the comb attachment/blade to cut its way through the hair. Do not force it through quickly. If you are cutting for the first time, start with the maximum comb attachment.

✳ **STEP 1 – Nape of the neck**

- Set the comb to 3mm or 6mm.
- Hold the clipper with the blade teeth pointing upwards. Begin starting at the centre of the head at the base of the neck.
- Slowly lift the clipper, working upwards and outwards through the hair, trimming just a little at a time.

✳ **STEP 2 – Back of the head**

- With the comb set at 12mm or 18mm, cut the hair at the back of the head.

✳ **STEP 3 – Side of the head**

- With the comb set at 3mm or 6mm, trim sideburns. Then change to the longer 9mm guide comb and continue to cut the top of the head.

✳ **STEP 4 – Top of the head**

- Use the longer length comb attachment and set it to 24mm or 27mm then cut hair on top of the head against the direction in which the hair normally grows.
- For longer hair on top, use the longer length comb attachment (24 – 44mm) to achieve the desired style.
- Always work from the back of the head.

★ **STEP 5 – The finishing touches**

- Use the clipper without an attachment comb for close trimming around the base and sides of the neck.
- To produce a clean straight line at the sideburns, reverse the hair clipper.
- Place the reversed clipper at right angles to the head, tips of the blades lightly touching the skin and then work downwards.

★ **AUTO TURBO SYSTEM**

- Push the power button and the appliance runs in Normal Mode. The Auto Turbo will automatically activate when the clipper senses it needs more power.
- To run in Turbo mode, hold down the power button for 2 seconds and the clipper will run in boost until it is turned off.

CARE FOR YOUR HAIRCLIPPER

- Your clipper is fitted with high quality blades.
- To ensure long lasting performance of your clipper, clean the blades and unit regularly.
- Always keep the attachment guide comb on the trimmer blade.

★ **AFTER EACH USE**

- Ensure the appliance is switched off and unplugged from the mains before cleaning.
- Brush the accumulated hair from the blades and body of the clipper.
- To clean unit, wipe with a damp cloth and dry immediately.
- Place a few drops of cutter or sewing machine oil onto the blades. Wipe off excess oil.

★ **WASHABLE BLADE CLEANING**

- ★ This clipper is fully washable and therefore can be rinsed under a running tap. However, avoid getting the micro USB port wet.
- To remove the blades ensure the unit is off. Press the blade release button on the back of the clipper when it meets the blade and push away from the clipper.
- To reattach once the blades are cleaned and dry, align the bottom of the blade with the bottom blade housing tab and slide the cartridge back into place until you hear a click.
- Do not run the entire unit under the tap, only the blade set is meant to be submerged in water.

✱ EVERY SIX MONTHS

- Remove the 2 screws retaining the fixed blade with a screwdriver. Do not remove blade set.
- Brush out hairs from between the blades with soft cleaning brush. Do not remove the lubricating grease from the blades. It is not necessary to remove the small moving blade from the unit.
- If the moving blade has been removed this can be re-fitted by slotting the coated blade holder over the pin in the centre of the interior product head.
- The groove on the coated blade, just below the teeth, rests on a metal plate at the opposite side to the screw holes. The fixed blade is fitted with the raised profile pointing outwards and fixed with the 2 screws.
- If the blades are not correctly aligned, cutting efficiency will be impaired.

✱ CLEANING CAUTIONS

- Ensure the appliance is switched off and unplugged from the mains before cleaning.
- Do not use harsh or corrosive cleaners on the units or their blades.



BATTERY REMOVAL

- The appliance must be disconnected from the supply mains when removing the battery.
- Turn the trimmer on and discharge all remaining power.
- Remove the comb attachment.
- Detach the blade cartridge.
- Pry the decorative panel off the top housing to expose the 6 screws located in the inner housing.
- Unscrew the 6 screws.
- Pry the inner housing apart from bottom housing to expose the internals and printed circuit board.
- Remove the battery and printed circuit board assembly from the battery chamber.
- Disconnect the battery from the circuit board.
- The battery is to be disposed of safely.



ENVIRONMENTAL PROTECTION

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol must not be disposed of with unsorted municipal waste, but recovered, reused or recycled.



➡ SERVICE AND GUARANTEE

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.

Your statutory rights are not affected.

Consumables are excluded.


Defects from repair by an unauthorized dealer are not covered.


If you call the Service Centre, please have the Model No. to hand, as we won't be able to help you without it. The Model No. can be found on the rating plate of the appliance.

Replacement parts and accessories are available to buy at
www.remington.co.uk/parts-accessories

➡ SERVICE CENTRE

United Kingdom

 Tel 0800 212 438 (free call mainland UK)

 +44 161 947 3111 (call outside the UK)

Spectrum Brands (UK) Ltd

Fir Street, Failsworth, Manchester

M35 0HS, UK

www.remington.co.uk

Ireland

 Tel 142 951 40

Remington Consumer Products,

Unit B12, Ballymount Corporate Park,

Ballymount, Dublin 12.

www.remington.co.uk

REGISTER ONLINE FOR

£10,000 prize draw, EXTRA year guarantee, FREE rewards gallery.

Visit www.remington.co.uk/productregister. You must register within 28 days of purchase.

Model No. HC5900

16/UK/ HC5900 T22-0004066 Version 05 /16

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.
Spectrum Brands (UK) Ltd

Fir Street,

Failsworth,

Manchester

M35 0HS

www.remington.co.uk

© 2016 Spectrum Brands, Inc.