# REMINGTON®

# **Rose Pearl Straightener**




S9505

remington-europe.com

# Register online for an EXTRA year guarantee

Visit uk.remington-europe.com/product-registration You must register within 28 days of purchase.



Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use. WARNING: This appliance is hot. Keep out of reach of children at all times.

## IMPORTANT SAFEGUARDS

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.



Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off
- For additional protection, the installation of a residual current device (RCD) . having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom\*.

\* Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the appliance is not permitted in the UK (see BS7671).

- Burn hazard. Keep the appliance out of reach from young children, • particularly during use and while cooling down.
- Never leave the appliance unattended when it is connected to the power supply.
- Always place the appliance with its stand, if any, on a heat-resistant, stable flat surface

- If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington<sup>®</sup> service dealer for repair or replacement in order to avoid a hazard.
- Do not allow any part of the appliance touch the face, neck or scalp.
- Keep the power plug and cord away from heated surfaces.
- · Do not use attachments other than those we supply.
- Do not use the appliance if it is damaged or malfunctions.
- Do not twist or kink the cable, or wrap it round the appliance. Check the cord regularly for any signs of damage.
- · This appliance is not intended for commercial or salon use.

#### PARTS

- 1. Advanced ceramic ultimate coated plates with real pearl
- 2. On/Off switch
- 3. Temperature controls
- 4. Temperature display

- 5. Heat boost function
- 6. Temperature lock function
- 7. Hinge lock
- 8. Heat resistant pouch (not shown)
- 9. Swivel cord

#### ADDITIONAL FEATURES

- Fast heat up—ready to use in 10 seconds.
- Automatic safety shut off this unit will switch itself off if no button is pressed or it is left on after 60 minutes.
- Multivoltage: for home or abroad. At 120V times and temperatures may vary.

#### INSTRUCTIONS FOR USE

- Before use, ensure the hair is clean, dry and tangle-free.
- For extra protection use a heat protection spray.
- Hairsprays contain flammable material do not use while using this product.
- Section the hair prior to styling. Style the lower layers first.
- 1. Plug the product into the mains power supply.
- 2. Press and hold the on/off button to switch on.
- 3. When the styler is plugged in but not turned on a lock symbol fit will show in the display window indicating the styler is in standby mode.

- Select the appropriate temperature for your hair type using the "+" and "--" temperature controls on the side of the product. Start styling on lower temperatures first.
- 5. The "+" button will increase the temperature and the "-" button will decrease the temperature.

#### Recommended Temperatures

Temperature	Hair type
150°C - 170°C	Thin / fine, damaged or bleached hair
170°C - 200°C	Normal, healthy hair
200°C - 235°C	Thick and difficult to style hair

- 6. The digital display will stop flashing when the product is ready to use.
- Working on one section at a time run the straightener through the entire length of the hair, without stopping.
- 8. Only repeat twice per section to prevent damage to the hair.
- 9. After use, press and hold the off button to turn off then unplug the appliance.

#### **Temperature Lock Function**

- Set the desired temperature using the +and buttons then lock the settings by
  pressing the "--" button for 2 seconds. The for symbol will appear on the temperature
  display.
- To unlock the temperature setting, press and hold the "--" button for 2 seconds.

#### **Temperature Boost Function**

- For quick touch ups of stubborn, hard to style sections.
- The temperature boost function boosts the temperature to 235°C.
- Hold the "+" button for 2 seconds to operate.
- Caution: the highest temperature is not suitable for every hair type. If you plan to
  use this straightener on the boost setting of 235°C please test on a small section of
  your hair first.

### STORAGE

#### Let the appliance cool down before cleaning and storing away

The plates can be locked together for easy storage:

To lock, push the hinge lock up to the locked position.

To unlock, pull the hinge lock down to the unlocked position

**NOTE**: Do not heat the unit in the locked position.

#### CLEANING AND MAINTENANCE

- Unplug the appliance and allow to cool.
- Wipe all the surfaces with a damp cloth.
- Don't use harsh or abrasive cleaning agents or solvents.

#### RECYCLING



To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/ collection point.

#### SERVICE AND GUARANTEE



Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under

any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the Crimea region.

To claim an extra 1 year guarantee, register your product online within 28 days of purchase.

Register at: https://uk.remington-europe.com/product-registration

Consumables are guaranteed only for their recommended lifecycle. Replacement/spare parts\* are excluded and are only covered by a 1 year warranty.

\*Examples include, but are not limited to, adaptors, haircare attachments, grooming accessories, etc.

#### SERVICE CENTRE

#### United Kingdom

O800 212 438 (free call mainland UK) Spectrum Brands (UK) Ltd Fir Street, Failsworth, Manchester M35 0HS, UK www.remington.co.uk Product support: product support@remington.co.uk

#### Ireland

142 951 40
 Remington Consumer Products,
 Unit B12, Ballymount Corporate Park,
 Ballymount, Dublin 12
 https://ie.remington-europe.com
 Product support:
 productsupport@remington.co.uk

# Ref. No. S9505

# Type No. S9500

20/UK/ S9505 T22-7001546 Version 09 /20 Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries. Spectrum Brands (UK) Ltd Fir Street, Failsworth, Manchester M35 0HS remington-europe.com

© 2020 Spectrum Brands, Inc.