
REMINGTON®

Keratin Protect 2200W Dryer









Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use. WARNING: This appliance is hot. Keep out of reach of children at all times.

IMPORTANT SAFEGUARDS

- This appliance can be used by children aged from 8 years and above and
 persons with reduced physical, sensory or mental capabilities or lack of
 experience and knowledge if they have been supervised/instructed and
 understand the hazards involved. Children shall not play with the
 appliance. Cleaning and user maintenance shall not be done by children
 unless they are older than 8 and supervised. Keep the appliance and cable
 out of reach of children under 8 years.
- Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- When the appliance is used in a bathroom, unplug it after use since the
 proximity of water presents a hazard even when the appliance is switched
 off
- For additional protection, the installation of a residual current device (RCD)
 having a rated residual operating current not exceeding 30 mA is advisable
 in the electrical circuit supplying the bathroom*.
 - * Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the appliance is not permitted in the UK (see BS7671).
- If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard.
- Always ensure the voltage to be used corresponds to the voltage stated on the unit before plugging the appliance into the mains socket.

- Keep direct airflow away from eyes or other sensitive areas.
- Do not allow any part of the appliance touch the face, neck or scalp.
- During use, always ensure the inlet and outlet grilles are not blocked in any way as
 this will cause the unit to automatically stop. If this should occur, switch off and allow
 the unit to cool.
- Keep the power plug and cord away from heated surfaces.
- Do not leave the appliance unattended while plugged in.
- Do not place the appliance on any soft furnishings.
- Do not use attachments other than those we supply.
- · Do not set the appliance down while still on.
- Do not twist or kink the cable, or wrap it round the appliance.
- · Do not use the appliance if it is damaged or malfunctions.
- Check the cord regularly for any sign damage.
- This appliance is not intended for commercial or salon use.
- WARNING: Contains traces of nuts.

PARTS

- Advanced ceramic grille infused with Keratin and Almond oil
- 2. Heat selector switch (\, \, \\)
- 3. Speed selector switch (0, **%**, **%**)
- 4. Cool shot

- 5. 7 mm concentrator
- 6. 11 mm concentrator
- 7. Diffuser
- 8. Inlet grille
- 9. Hang up loop

INSTRUCTIONS FOR USE

- 1. Wash and condition your hair as normal.
- Squeeze out excess moisture with a towel and comb through.
 Hairsprays contain flammable material do not use while using this product.
- Attach diffuser/concentrators by fitting them to the front of the hairdryer and twisting clockwise to lock.
- 4. Plug the product into the mains power supply.
- Switch your hairdryer on and select the desired speed setting (low 2 or high 2) using the speed selector switch.
- Select the desired heat setting (low \(\), medium \(\) or high \(\)\(\)) using the heat selector switch.
- 7. After use, turn the appliance off and unplug it.
- 8. Let the appliance cool down before cleaning or storing away.

TIPS

- For fast drying use the high heat / high speed function.
- To create smooth styles use the concentrator and a round hair brush (not included) whilst drying.
- To enhance natural curls and waves, attach the diffuser to the dryer. Turn your head
 upside down and gently place your hair into the diffuser bowl slightly rotating the
 dryer as you style.
- To create extra volume at the roots of the hair, keep your head upright and place the
 diffuser against the top of the head. Gently rotate the hairdryer allowing the diffuser
 fingers to gently massage the scalp being careful not to burn the scalp. Dry gently on
 a medium heat / low speed setting.
 - Caution: Do not use the diffuser on the highest heat setting (\(\)).
- To set your style, press the cool shot button whilst styling.

CLEANING AND MAINTENANCE

- Unplug the appliance and allow to cool.
- To maintain peak product performance and to prolong motor life, it is important to regularly remove any dust and dirt from the air filter grille.
- Remove the grille as shown (FIG A), clean with a cloth or soft brush, then replace it.

RECYCLING





To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/collection point.

SERVICE AND GUARANTEE

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.

Your statutory rights are not affected.

Consumables are excluded.

Defects from repair by an unauthorized dealer are not covered.

If you call the Service Centre, please have the model number to hand, as we won't be able to help you without it. The model number can be found on the rating plate of the appliance.

Replacement parts and accessories are available to buy at www.remington.co.uk/parts-accessories

SERVICE CENTRE

United Kingdom

Tel 0800 212 438 (free call mainland UK)
+44 161 947 3111 (call outside the UK)
Spectrum Brands (UK) Ltd
Fir Street, Failsworth, Manchester

M35 0HS, UK www.remington.co.uk

Ireland

Tel 142 951 40
Remington Consumer Products,
Unit B12, Ballymount Corporate Park,
Ballymount, Dublin 12.
www.ie.remington-europe.com

𝒯 REGISTER ONLINE FOR

£10,000 prize draw, EXTRA year guarantee, FREE rewards gallery.

Visit www.remington.co.uk/productregister. You must register within 28 days of purchase.

Ref. No. AC8008

18/UK/ AC8008 T22-7000098 Version 01 /18

AC8000

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries. Spectrum Brands (UK) Ltd

Fir Street. Failsworth,

Manchester

M35 0HS

www.remington.co.uk

© 2018 Spectrum Brands, Inc.