
REMINGTON® EST. NEW YORK 1937



Advanced Coconut Therapy AC Hairdryer AC8648

Register online for an EXTRA year guarantee

Visit uk.remington-europe.com/product-registration You must register within 28 days of purchase.



Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use. WARNING: This appliance is hot. Keep out of reach of children at all times.

IMPORTANT SAFEGUARDS

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.



Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched ٥ff
- For additional protection, the installation of a residual current device (RCD) • having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom*.

* Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the appliance is not permitted in the UK (see BS7671).

- If the supply cord of this unit becomes damaged, discontinue use • immediately and return the appliance to your nearest authorised Remington[®] service dealer for repair or replacement in order to avoid a hazard
- Always ensure the voltage to be used corresponds to the voltage stated on the unit before plugging the appliance into the mains socket.

- Keep direct airflow away from eyes or other sensitive areas. .
- Do not allow any part of the appliance touch the face, neck or scalp.
- During use, always ensure the inlet and outlet grilles are not blocked in any way as this will cause the unit to automatically stop. If this should occur, switch off and allow the unit to cool
- Keep the power plug and cord away from heated surfaces.
- Do not leave the appliance unattended while plugged in.
- Do not place the appliance on any soft furnishings. •
- Do not use attachments other than those we supply.
- Do not set the appliance down while still on.
- Do not twist or kink the cable, or wrap it round the appliance.
- Do not use the appliance if it is damaged or malfunctions.
- Check the cord regularly for any sign damage.
- This appliance is not intended for commercial or salon use.

PARTS

- Outlet grille with advanced 1 conditioning technology
- Heat selector switch (), (), (())
- Speed selector switch (0, 2, 2)
- 4 Cool shot
- 5. Intelligent heat sensor light

INSTRUCTIONS FOR USE

- Wash and condition your hair as normal. 1.
- 2. Squeeze out excess moisture with a towel and comb through. Hairsprays contain flammable material – do not use while using this product.
- 3. Fit accessory attachments to the front of the hairdryer then twist clockwise to lock in place. Take care when you do this because the attachments can become hot during use.
- 4. Plug the product into the mains power supply.
- 5. Switch your hairdryer on and select the desired speed setting (low **x** or high **X**) using the speed selector switch.
- 6. Select the desired heat setting (low \, medium \) or high \)) using the heat selector switch.
- After use, turn the appliance off and unplug it.
- 8. Let the appliance cool down before cleaning or storing away.

- 6. 7 mm concentrator
- 7. 11 mm concentrator
- 9. Inlet arille
- 10. Intelligent heat sensor on/off button
- 11. Hang up loop
- 8. Diffuser

Intelligent Heat Sensor

- Press the ∞ button to activate the Intelligent Heat Sensor.
- If the sensor is on during styling, the indicator light will come on to show that the sensor is monitoring the air temperature and continually regulating the heat output, helping to prevent the damage caused by overheating.
- Note the function only operates on med-high heat settings and the light will come on to show when it is operating.

TIPS

- For fast drying use the high heat / high speed function.
- To create smooth styles use the concentrator and a round hair brush (not included) whilst drying.
- To enhance natural curls and waves, attach the diffuser to the dryer. Turn your head
 upside down and gently place your hair into the diffuser bowl slightly rotating the
 dryer as you style.
- To create extra volume at the roots of the hair, keep your head upright and place the diffuser against the top of the head. Gently rotate the hairdryer allowing the diffuser fingers to gently massage the scalp being careful not to burn the scalp. Dry gently on a medium heat / low speed setting.

Caution: Do not use the diffuser on the highest heat setting ()).

• To set your style, press the cool shot button whilst styling.

STORAGE, CLEANING AND MAINTENANCE

Let the appliance cool down before cleaning and storing away

- To maintain peak product performance and to prolong motor life, it is important to regularly remove any dust and dirt from the inlet grille.
- Remove the grille as shown (FIG A), clean with a cloth or soft brush, then replace it.

OVERHEAT PROTECTION

In the event of overheating, the appliance may either stop unexpectedly or start to blow cold air. Overheating is usually caused by a blocked grille/filter. If this happens, immediately unplug the appliance and refer to STORAGE, CLEANING AND MAINTENANCE to clean the grille/filter. If, after doing this overheating continues to happen, stop using the appliance and contact Customer Service.

RECYCLING



To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/ collection point.

SERVICE AND GUARANTEE



Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. To claim an extra 1 year guarantee, register your product online within 28 days of purchase.

This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the Crimea region.

Register at: https://uk.remington-europe.com/product-registration

Consumables are guaranteed only for their recommended lifecycle. Replacement/spare parts* are excluded and are only covered by a 1 year warranty.

*Examples include, but are not limited to, adaptors, haircare attachments, grooming accessories, etc.

SERVICE CENTRE

United Kingdom

0800 212 438 (free call mainland UK) Spectrum Brands (UK) Ltd Fir Street, Failsworth, Manchester M35 0HS, UK www.remington.co.uk Product support: product support@remington.co.uk

Ireland

142 951 40
 Remington Consumer Products,
 Unit B12, Ballymount Corporate Park,
 Ballymount, Dublin 12
 https://ie.remington-europe.com
 Product support:
 productsupport@remington.co.uk

Ref. No. AC8648 Type No. D11A

20/UK/ AC8648 T22-7001349-B Version 04 /20 Remington[®] is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries. Spectrum Brands (UK) Ltd Fir Street, Failsworth, Manchester M35 0HS www.remington.co.uk

© 2020 Spectrum Brands, Inc.