





Russell Hobbs

A BRITISH ICON SINCE 1952

27170AU

 www.russellhobbs.com.au
 www.russellhobbs.co.nz





IMPORTANT SAFEGUARDS

When using this appliance, basic safety precautions should always be followed, including the following:
Read all instructions before, and follow whilst using this appliance.

1. To protect against electrical hazards, do not immerse the air fryer body in water or any liquid.
2. Do not use it in a bathroom or near any source of water. 
3. Do not use outdoors.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
5. This appliance is NOT a toy. Children should be supervised to ensure they do NOT play with this appliance.
6. Always follow the instructions when using this appliance.
7. The temperature of accessible surfaces/parts may become very hot when the appliance is operating and may remain hot for some time after the appliance has been switched off.
8. To avoid the possibility of scalding, keep clear of steam escaping around the door area.
9. CAUTION: Do not touch any internal surfaces until the air fryer has fully cooled.
10. CAUTION: Do not operate on an inclined plane. Place the air fryer on a stable, level, heat-resistant surface and out of reach of children.
11. Route the power cord so it does not overhang, and cannot be caught accidentally.
12. Unplug the air fryer when not in use, before moving and before cleaning. Let it cool down fully before cleaning and storing away.
13. There are no user serviceable parts. If the power cord is damaged, it must be replaced by the manufacturer or similarly qualified person in order to avoid hazard.
14. Do not operate this appliance with a damaged cord/plug or after the appliance has malfunctioned, or been dropped or damaged in any manner. Contact Customer Service for examination, adjustment, repair or replacement.
15. To shut down, press , turn off the wall power outlet then grasp the plug and remove from wall power socket. Never pull by the cord.
16. Leave a clear space of at least 50mm around the air fryer when in use.
17. Do not cover the air fryer or put anything on top of it while in use.
18. Do not use the air fryer near or below curtains, overhead cupboards or other combustible materials.
19. Keep the power cord and the air fryer away from hotplates, cook-tops and burners.
20. Cook meat, poultry, and derivatives (mince, burgers, etc.) till the juices run clear. Cook fish till the flesh is opaque throughout.
21. Do not pour oil or any other liquid into the basket.
22. Do not use accessories or attachments other than those supplied as specifically for use with the air fryer.
23. Do not use the air fryer for any purpose other than that described in these instructions.
24. Do not connect this air fryer to an external timer or remote control system.





25. For added safety, electrical appliances should be connected to a power outlet that is protected by a residual current device (RCD), also often referred to as a 'Safety Switch'. Your switchboard may already incorporate an RCD. If unsure, call an electrician for verification and fitting if necessary.

This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- farm houses.

CAUTION: Benchtops, such as, but not limited to, engineered stone, marble, granite and acrylic may not be tolerant of localised temperature rises. Therefore, any appliance that radiates heat should be placed on a heat resistant pad or chopping board to prevent the heat from affecting the benchtop.

SAVE THESE INSTRUCTIONS

PARTS

- | | |
|-------------------------------|-----------|
| 1. Touch controls and display | 4. Basket |
| 2. Body | 5. Handle |
| 3. Crisping plate | |

BEFORE USING FOR THE FIRST TIME

- Handwash the removable parts, rinse, and dry.
- When using your air fryer for the first time, you may notice smoke or a slight odour for the first few minutes of cooking. This is normal. Ensure the room is well ventilated.

PREPARATION

- Sit the appliance on a stable, level, heat-resistant surface.
- Leave a space of at least 50mm all-round the appliance.
- Have oven gloves (or a tea towel) on hand, use heat resistant plastic tongs and a heat-resistant mat or dinner plate to rest the basket on.
- Note: Do not use metal tongs as it may scratch the coating. We recommend using only heat resistant plastic or silicon coated tongs.
- Your air fryer may be shipped with the handle detached from the basket. If required, remove the basket and attach the handle by sliding it downwards into the opening until it clicks into place. Make sure that the handle is locked into place before use. Once fitted, the handle cannot be removed.

To remove the basket from the body

1. Hold the top of the body.
2. Grip the basket handle with the other hand.
3. Slide the basket out of the body.
4. Rest the basket on a heat-resistant mat.

To adjust the crisping plate:

The crisping plate can be adjusted to a high or low position to allow food to be positioned closer to or further from the element during cooking.

1. There are supports inside the basket (Fig. A).
2. For the low position, place the crisping plate on the bottom of the basket (Fig. B).
3. For the high position, place the crisping plate on the supports inside the basket (Fig. C).





DIGITAL TOUCHSCREEN

ICON	DESCRIPTION
	On/Off
	Preset functions
	Used to adjust the cooking temperature in conjunction with the ^ or v buttons.
	Used to adjust the cooking time in conjunction with the ^ or v buttons.
	Increase/decrease
	Time/Temperature Display

PRESET FUNCTIONS

Your air fryer has the following cooking functions. You can adjust the default cooking times and temperatures as desired.

Function		Default Cooking Time (mins)	Default Temperature (°C)	Shake Reminder
Fries		18	205	Yes
Vegetables		8	195	Yes
Bake		30	160	No
Fish		10	200	No
Eggs		18	120	No
Chicken		40	180	Yes
Grill		12	205	Yes
Reheat		12	115	Yes
Defrost		15	85	Yes
Dehydrate		120	50	No

ADJUSTING THE COOKING TIME OR THE TEMPERATURE

- Once you have selected the desired cooking mode, tap the (i) icon and then tap the (^) and (v) icons to increase or decrease the cooking temperature as desired.
- To adjust the cooking time, tap the (🕒) icon and then tap the (^) and (v) icons to increase or decrease the cooking time as desired.





USING

- Your air fryer uses hot air and radiant heat for cooking.

Preheating

1. Set the cooking time to 5 minutes.
2. Tap the on/off icon (⏻) to start the preheating cycle.
3. When the cooking time reaches zero, your air fryer will beep 5 times and switch off.

Cooking

1. Place the crisping plate inside the basket.
2. Place desired food into the cooking basket. Do not overfill the basket, to leave space for the hot air to circulate between pieces of food.
3. Slide the basket back into the air fryer body, ensuring it clicks into place and sits flush within your air fryer body. Your air fryer will not work unless the basket is properly inserted.
4. Once the basket has been correctly inserted, the control panel will be illuminated.
5. Tap the (⏻) power icon. Your air fryer will show a default cooking time of 15 minutes and a default temperature of 190°C.
6. Select the desired preset function.
7. Make any adjustments to the cooking time or temperature as required (see **Adjusting the cooking time or temperature**).
8. Tap the (⏻) icon to start cooking.
 - To stop cooking at any time tap the (⏻) icon.
9. Once the cooking time has elapsed, the timer will beep 5 times and the unit will switch off.
10. Slide the basket out of the body and check that the food is cooked.
11. Place the basket on an insulated mat.

Notes

- To remove food from the basket, we recommend using tongs. We do not recommend tipping the basket upside down as oil residue will drip out.
- CAUTION: Hot oil from the ingredients may gather at the bottom of the basket. Be careful when removing the crisping plate from the basket.
- Unplug the appliance, once all cooking is complete.
- Your air fryer will switch off when you remove the basket.
- Your air fryer will switch back on when you replace the basket in to the body and will automatically resume the cooking cycle from where it stopped.

Shake Reminder

To ensure even cooking, some foods require shaking or turning during cooking. Some of the built in presets include a reminder. Your air fryer will beep and the **SHAKE** icon will flash when the reminder is active. Carefully remove the basket and gently shake it, or use tongs to turn the food.

Note

If you do not remove the basket and shake the food, the **SHAKE** icon will remain lit.

COOKING TIMES AND FOOD SAFETY

- To be used purely as a guide
- Check food is cooked through before serving. If in doubt, cook it a bit more.
- Cook meat, poultry, and any derivatives (mince, burgers, etc.) till the juices run clear.
- Cook fish till the flesh is opaque throughout.
- When cooking pre-packed foods, follow any guidelines on the package or label.



Food	Temperature °C	Time (min)	Remarks
Chips	200	25	Rinse, dry, toss in salt, pepper, and oil
Potato wedges	200	15-20	Rinse, dry, toss in salt, pepper, and oil
Sweet potato wedges	200	15-20	Rinse, dry, toss in salt, pepper, and oil
Jacket potato	180	30-40	For a crispy jacket, brush with oil
Roast potatoes	180	25-35	Rinse, dry, toss in salt, pepper, crushed rosemary (optional) and oil
Mixed Mediterranean vegetables	180	6-10	All cut to similar sizes, approx. 1-2cm pieces, toss in oil and season
Chicken Breast	180	15-20	
Chicken Thighs	180	25-30	Cooking time depends on size. Brush with oil, season
Chicken wings	180	23-28	Cooking time depends on size. brush with oil, season
Burgers	180	8-12	Cooking time depends on size. brush with oil, season
Sausages	180	8-12	
Pork chop	180	22	Brush with oil, season
Salmon fillet	180	8-12	Brush with oil, season
White fish fillet	180	8-12	Brush with oil, season
Sausage Roll	200	13-15	Brush with oil, season
Spring Roll	200	8-10	
Muffins	180	15-18	
Frozen Food	Temperature °C	Time (min)	Remarks
Chips	200	25	
Potato wedges	200	15-20	
French fries	200	12-20	
Chicken Nuggets	200	6-10	
Fish fillets	200	10-12	
Fish Fingers	180	6-10	
Onion Rings	180	10-15	
Scampi	180	15	

NOTE: High fat foods (e.g. pork) may create smoke. This is normal as oil residue is cooked at a high temperature. Reducing temperature may decrease the effect of smoke.



CARE AND MAINTENANCE

- Unplug the appliance.
- Leave everything to cool down.

Basket and Crisping Plate

1. Once the air-fryer has cooled, remove the basket from the air-fryer body for cleaning.
 2. Wipe the interior of the body to remove any crumb or residue, but **DO NOT** wipe the heating elements located at the top.
 3. Remove the crisping plate from the basket.
 4. Dispose of food residue and oils, and wipe both the crisping plate and basket with a damp cloth before hand washing them in warm to hot soapy water. Dry thoroughly before placing back in the air fryer body.
- The basket and crisping tray can also be washed in a dishwasher.

Exterior Surfaces

- Clean the exterior with a damp cloth or sponge. Dry thoroughly.

RECYCLING

Legislation in some localities mandates that e-waste (anything with a plug, battery or cord) is disposed of through controlled recycling facilities and must not be disposed of in general household waste. For more information about recycling of electrical and battery operated appliances, please contact your local council or your local household waste disposal service.



Spectrum brands Australia Pty Ltd
Locked Bag 3004 Braeside
Victoria 3195 Australia

Customer Service in Australia
TollFree: 1800 623 118
Email: info@spectrumbrands.co.au
Website: www.spectrumbrands.co.au

Spectrum Brands New Zealand Ltd
PO Box 9817 Newmarket
Auckland 1149 New Zealand

Customer Service in New Zealand
TollFree: 0800 736 776
Email: service@spectrumbrands.co.nz
Website: www.spectrumbrands.co.nz

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Ltd Warranty Against Defects

In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

CGA means the New Zealand Consumer Guarantees Act 1993;

Goods means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ABN, 78 007 070 573;
or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Ltd, as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for a (Warranty Period) period of 2 years from the date of purchase.

If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Exhaustible components (such as batteries, filters and brushes) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.
8. In order to claim under the warranty granted under clause 3 you must:
 - (a) Retain this warranty with your receipt/proof of purchase; and
 - (b) Return the Goods to us at the relevant address or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
 - (a) Any serial number or appliance plate is removed or defaced;
 - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Ltd.

Contact us or the Supplier for further details.

Register your product online


If you live in Australia please visit: www.spectrumbrands.com.au/warranty

If you live in New Zealand Please visit: www.spectrumbrands.co.nz/warranty

Registration of your warranty is not compulsory, it gives us a record of your purchase AND entitles you to receive these benefits: Product information; Hints and tips; Recipes and news; Information on special price offers and promotions.

Any questions? Please contact Customer Service for advice.



BEAUTIFULLY BRITISH IDEAS
SINCE

1952

T22-9003227