

# REMINGTON®

EST. NEW YORK 1937




## **G6 Graphite Series Personal Groomer PG6000**

 [www.remington.co.uk](http://www.remington.co.uk)

**Register online for an EXTRA year guarantee**


Visit [uk.remington-europe.com/product-registration](http://uk.remington-europe.com/product-registration) You must register within 28 days of purchase.



Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.



## IMPORTANT SAFEGUARDS

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
- The adaptor contains a transformer. Do not cut off the adaptor to replace it with another plug, as this causes a hazardous situation.
-  Suitable for use in a bath or shower.
- **WARNING:** Detach the device from the charging adapter before cleaning it in water.
- Do not use the product with a damaged cord.
- **WARNING:** For recharging the battery, only use the charger supplied with the appliance - type reference PA-0505U.
- Always replace a damaged adaptor with one of the original type.
- The battery in this device is not replaceable.
- Do not use the appliance if it is damaged or malfunctions.
- Do not use attachments other than those we supply.
- This appliance should never be left unattended when plugged into a power outlet, except when charging.
- Keep the power plug and cord away from heated surfaces.
- Do not plug or unplug the appliance with wet hands.
- Do not twist or kink the cable, or wrap it round the appliance.
- This appliance is not intended for commercial or salon use.

## PARTS

- |                             |                               |
|-----------------------------|-------------------------------|
| 1. On/Off switch            | 8. Nose, ear, eyebrow trimmer |
| 2. Charging indicator light | 9. Mini foil shaver           |
| 3. Charging connector       | 10. Deep cleansing brush head |
| 4. Wide trimmer             | 11. Body hair trimmer         |
| 5. Adjustable comb          | 12. Body hair trimmer comb    |
| 6. Fixed guide combs        | 13. Adaptor (not shown)       |
| 7. Precision trimmer        | 14. Storage pouch (not shown) |

## CHARGING YOUR APPLIANCE

Before using your trimmer for the first time, charge for 4 hours.

1. Ensure the product is switched off.
2. Connect the charging adaptor to the product and then to the mains.

### CHARGING INDICATOR LIGHT

Charge Level	Indicator
Charging	Blue LED will flash
Fully Charged	Blue LED will light up continuously
Battery charge is low	Red LED will flash

- Your trimmer cannot be overcharged. However, if it is not going to be used for an extended period of time (2-3 months), unplug it from the mains and store.
- To preserve the life of your batteries, let them run out every 6 months then recharge for 4 hours.
- On a full charge, your trimmer will run for up to 90 minutes of cordless usage.

## ATTACHMENTS

### TO FIT AND REMOVE ATTACHMENTS (FIG. A)

Ensure that the device is switched off before fitting or removing attachments.

- To remove, rotate the attachment anti-clockwise until it unlocks and then lift it off.
- To fit, place the desired attachment on top of the device and rotate the attachment clockwise to lock it into place.

**FITTING AND REMOVING FIXED GUIDE COMBS****To Fit**

- Hook the front of the guide comb over the teeth of the wide trimmer.
- Press the back of the guide comb down until it clicks into place.

**To Remove**

- Lift the tab on the back of the guide comb upwards until it comes free from the wide trimmer head.

**FITTING AND REMOVING THE ADJUSTABLE COMB**

- To fit, line up the rails on the comb with the slots on the sides of the groomer and slide the comb downwards onto the groomer.
- To adjust, press and hold the adjustment button on the back of the comb and slide the comb up or down. Release the button to lock the comb at that position. The length of cut is indicated by the scale on the side of the trimmer.
- To remove, press and hold the adjustment button and push the comb up and off the groomer.

**INSTRUCTIONS FOR USE**

- Comb facial hair with a fine comb before you start trimming.
- Comb your hair in the direction that it grows so that the hairs are at their maximum height and facing in the same direction.
- After trimming, lightly go over the trimmed areas with the foil to get a smooth clean finish.
- Since all hairs do not grow in the same direction, you may want to try different trimming positions (i.e. upwards, downwards or across) for better results.
- Hair should be dry and free from any waxes or lotions.
- If hair builds up during use, switch the unit off, remove any attachment in use and clean any excess hair clippings from the attachment and groomer.

**3-DAY STUBBLE, AND BODY HAIR MAINTENANCE**

<b>Attachments</b>
Wide trimmer with 1.5 mm fixed comb
Body hair attachment

**3-day stubble look:**

Let your stubble grow to a length that is slightly longer than the look you are trying to achieve.

1. Fit the 1.5 mm fixed comb to the wide trimmer attachment.
2. Run your trimmer through your beard against the direction of hair growth.

3. Tidy the edges of the stubble using the precision trimmer attachment.
- For more control over the length of your stubble, you can use the adjustable comb and trim your stubble down in increments starting at a longer length setting until you get the desired look.

## **Body hair maintenance: Trimming to length**

1. Fit the body hair attachment.
2. Body hair can be trimmed to 3 different lengths (3, 6 and 9 mm). Select the desired length by sliding the comb into one of the three slots on the side of the attachment.
3. Place the flat side of the attachment against the skin.
4. Slowly slide the trimmer through the hair in the direction of hair growth.
5. Use slow, well-controlled movements.

## **Body hair maintenance: Removal**

1. Remove the comb from the body hair attachment and go over the areas where you want to remove the body hair.
2. Stretch the skin with your free hand to make the hairs stand upright.
3. Use light pressure and shave against the direction of hair growth.

## **HAIR CLIPPING**

### **Attachments**

Wide trimmer with adjustable comb

### **Step 1: Nape of the neck**

1. Fit the wide trimmer and adjustable comb.
2. Set the adjustable comb to 4 mm or 6 mm.
3. Hold the clipper with the blade teeth pointing upwards. Begin starting at the centre of the head at the base of the neck.
4. Slowly lift the clipper, working upwards and outwards through the hair, trimming just a little at a time.

### **Step 2: Back of the head**

- With the comb set at 12 mm or 18 mm, cut the hair at the back of the head.

### **Step 3: Side of the head**

1. Adjust the comb to a shorter length setting for the areas around the ears.
2. Increase the length setting on the adjustable comb to gradually transition the length of hair on the side of the head to the longer hair on the top of the head.

### **Step 4: Top of the head**

1. Adjust the comb to the longer length settings (up to 20 mm) then cut the hair on top of the head against the direction in which the hair normally grows.
2. Always work from the back of the head.

**Trim the sideburns**

- To trim the sideburns, adjust the comb to the desired length setting, or use one of the fixed guide combs.

**SHORT/LONG BEARD TRIMMING**

<b>Attachments</b>
Wide trimmer with adjustable comb
Precision trimmer

1. Fit the wide trimmer and adjustable comb.
2. Set the adjustable comb to the desired length.
3. Start trimming under the chin following the line of the jaw.
4. Work upwards towards the ear and upper beard line.
5. Tidy the beard edges using the precision trimmer attachment.

**CONTOUR EDGING AND CLOSE HAIR CUTTING**

<b>Attachments</b>
Wide trimmer

**Contour edging:**

1. Hold the device with the cutting blade (teeth) facing you and at 90 degrees to the skin.
2. Start with the edge of the beard/moustache line and, with the blade resting lightly against the skin, use slow controlled movements to create contoured lines.

**Close hair cutting:**

1. Use the fingers of one hand to lift the hair at the base of your head up off your neck.
2. Your index finger should be covering the roots of the hairs you are lifting to prevent them from being accidentally cut.
3. Hold the trimmer to the base of your neck with the blade facing up. Move the trimmer up the neck until it touches your index finger which is protecting the hair roots.
4. Move your trimmer slowly and keep the hair roots at the base of your head out of the way of the trimmer.

**DETAILED NOSE, EYEBROW AND EAR HAIR TRIMMING**

<b>Attachments</b>
Nose, ear and eyebrow trimmer

**Nose and ear:**

1. Fit the nose, ear and eyebrow trimmer.

2. Insert the attachment gently into the nostril or ear.
3. Gently move the attachment in and out while rotating the body of the groomer at the same time.
  - Don't insert the attachment more than 6 mm.
  - Wash the attachment after each use.

## ***Eyebrow:***

1. Carefully guide the attachment to remove any stray or longer hairs from the eyebrow.
2. To completely remove hairs, let the attachment touch the skin then move over the desired area.

## **MICRO STUBBLE AND PRECISION TRIMMING**

### ***Attachments***

Precision trimmer

## ***Micro stubble:***

The precision trimmer attachment has Trim Shave Technology which trims hair down to 0.2 mm to leave a micro stubble finish.

1. Fit the precision trimmer.
2. Hold the attachment so that the guide on the lower edge of the blade contacts the skin (the same way you would hold a wet razor). The guide on the lower edge of the blade helps to stretch the skin during trimming.
3. Use motions similar to wet shaving.

## ***Precision trimming:***

1. Hold the precision trimmer attachment perpendicular to the skin.
2. Move it towards or away from the beard hair to achieve the desired result. Use gentle pressure and controlled movements.

## **DEEP CLEANSING BRUSH HEAD**

### ***Attachments***

Deep cleansing brush head

1. Moisten the brush bristles by running under water. NOTE: DO NOT use the brush head whilst completely dry as this can cause skin irritation.
2. Dampen your skin with water and apply face wash onto your skin. Alternatively, apply your face wash directly onto the brush.
3. We recommend cleansing with the Deep Cleansing brush in 3 sections:
  - T-Zone (1), Right side (2) and Left side (3).
4. Switch on using the On/Off button.



- Place the facial brush directly onto your skin.
- Gently glide the brush over the skin and beard in circular motions avoiding the delicate eye area.

**NOTE:** Try to avoid applying too much pressure with the brush when directly on the skin.

## CLEAN SHAVEN EDGING

### *Attachments*

Mini Foil Shaver
------------------

- Hold the trimmer so the mini foil shaver gently touches your face.
  - Use short, well-controlled movements to shave around your beard moustache. Use your free hand to stretch your skin. This encourages the hair to stand upright, making it easier to shave.
- Note: The mini foil shaver was designed to shave the detail areas around your beard/moustache/sideburns. It was not designed to shave your entire face. For a close comfortable shave, guaranteed, use one of Remington's electric shavers.

## CARE FOR YOUR GROOMER

Care for your product to ensure a long lasting performance. We recommend that you clean your groomer after each use.

### AFTER EACH USE

- Brush any accumulated hairs from the groomer and attachment heads.
- The easiest and most hygienic way to clean the groomer is by detaching the head from the groomer body and rinsing the head with warm water.
- The groomer body should not be rinsed.
- Place one or two drops of cutter oil or sewing machine oil on the blades.
- Turn the clipper on to distribute the oil evenly, wipe off any excess oil.

## BATTERY REMOVAL

We strongly recommend that a professional removes the rechargeable battery. Parts of the shaver case, and tools have sharp edges and may cause injury if not handled correctly.

- The rechargeable battery must be removed from the appliance before it is scrapped.
  - Disconnect the charging adapter before removing the battery.
- Ensure the device is discharged of all power. To do this, switch it on and allow it to run until it stops.
  - Using a suitable tool, carefully pry apart the front and rear halves of the case at the joint line.

3. Remove the two screws that hold the transparent inner case to the back half of the outer case.
  4. Lift out the inner case.
  5. Pull the black motor holder off the transparent case.
  6. Slide the circuit board and battery out of the transparent inner case.
  7. Cut the tabs holding the battery to the circuit board.
- Used batteries must be removed from the appliance and disposed of at an appropriate official recycling/collection point.
  - Do not attempt to operate the shaver once you have opened it.

## RECYCLING



To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/collection point.

## SERVICE AND GUARANTEE



Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected.

This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under

any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the Crimea region.

To claim an extra 1 year guarantee, register your product online within 28 days of purchase.

Register at: <https://uk.remington-europe.com/product-registration>

Consumables are guaranteed only for their recommended lifecycle. Replacement/spare parts\* are excluded and are only covered by a 1 year warranty.

\*Examples include, but are not limited to, adaptors, haircare attachments, grooming accessories, etc.

---

**SERVICE CENTRE**

---

**UNITED KINGDOM**

 0800 212 438 (free call mainland UK)

Spectrum Brands (UK) Ltd


Fir Street, Failsworth, Manchester

M35 0HS, UK

[www.remington.co.uk](http://www.remington.co.uk)

[productsupport@Remington.co.uk](mailto:productsupport@Remington.co.uk)

**IRELAND**

 142 951 40

Remington Consumer Products,

Unit B12, Ballymount Corporate Park,

Ballymount, Dublin 12

<https://ie.remington-europe.com>

[productsupport@Remington.co.uk](mailto:productsupport@Remington.co.uk)

شكرا لقيامك بشراء منتج Remington® الجديد. يرجى قراءة هذه التعليمات بعناية والاحتفاظ بها في مكان آمن. قم بإزالة جميع مواد التعبئة قبل الاستخدام.

### إجراءات وقائية هامة

- يمكن استخدام هذا الجهاز بواسطة الأطفال الذين تتراوح أعمارهم من 8 سنوات وما فوق والأشخاص ذوي القدرات البدنية أو الحسية أو العقلية المنخفضة أو قليلي الخبرة والمعرفة إذا تم الإشراف عليهم/إرشادهم ويفهمون المخاطر المعنية. ويجب ألا يعبث الأطفال بالجهاز. ويجب ألا يقوم الأطفال بالتنظيف والصيانة إلا إذا كان عمرهم أكبر من 8 سنوات وتحت إشراف.
- لا تستخدم هذا المنتج إذا كان لا يعمل بشكل صحيح، في حالة ما إذا تم إسقاطه أو إتلافه، أو إسقاطه في الماء
- يحتوي المحول على محول. لا تقطع المحول لاستبداله بمقبس آخر لأن ذلك يسبب وضعاً خطراً.



- مناسب للاستخدام في حمام أو دش.
- تحذير: يجب فصل الجهاز من محول الشحن قبل تنظيفه بالماء.
- لا تستخدم المنتج مع سلك تالف.
- تحذير: لإعادة شحن البطارية، يجب استخدام الشاحن المرفق فقط مع الجهاز - مرجع النوع PA-0505U.
- استبدل دائماً المحول التالف أو قاعدة الشحن بأخرى من النوع الأصلي.
- البطارية غير قابلة للاستبدال.
- لا تستخدم ملحقات غير الملحقات التي تقوم بتوريدها.
- لا تستخدم الجهاز إذا كان تالفاً أو لا يعمل بصورة صحيحة.
- لا ينبغي أبداً أن تترك الجهاز بعيداً عن انتباهك أثناء توصيله بمصدر تيار كهربائي، إلا عند الشحن
- حافظ على قابس الطاقة والسلك الكهربائي بعيداً عن الأسطح الساخنة
- لا تقم بتوصيل أو فصل الجهاز بأيدي متبللة.
- لا تقم بتثني أو جدل الكبل أولفه حول الجهاز.
- دع الجهاز يبرد قبل تنظيفه وتخزينه.

### الأجزاء

- |  |                                 |
|--|---------------------------------|
| 1. مفتاح تشغيل/إيقاف (On/off)          | 9. رأس ملحق ماكينة حلقة الرقاقة |
| 2. لمبة مؤشر الشحن                     | 10. رأس فرشاة التنظيف العميق    |
| 3. موصل الشاحن                         | 11. ملحق شعر الجسم              |
| 4. جهاز التشذيب العريض                 | 12. مشط                         |
| 5. المشط القابل للتعديل                | غير مبين:                       |
| 6. مشط دليل ملحق                       | • قاعدة الشحن                   |
| 7. رأس التشذيب الدقيق                  | • جراب للتخزين                  |
| 8. ملحق تشذيب شعر الأنف والأذن والحاجب |                                 |

قبل استخدام طقم تشذيب اللحية والتزوين لأول مرة، اشحن الوحدة لمدة 4 ساعات للأداء الأمثل.

1. تأكد من إيقاف الجهاز.
2. قم بتوصيل محول الشحن بالمنتج ثم بالكهرباء.

مؤشر الشحن

مستوى الشحن	مؤشر الشحن
الشحن	تومض لمبة المؤشر الزرقاء
شحن منخفض	ستضيء لمبة المؤشر الأزرق بشكل مستمر
شحن منخفض	تومض لمبة المؤشر الحمراء

- تصل مدة التشغيل من الشحن الكامل إلى 90 دقيقة.
- لا يمكن شحن المقص أكثر من اللازم. ومع ذلك افصله من الكهرباء وقم بتخزينه إذا كان المنتج لن يستخدم لمدة طويلة (2-3 شهر).
- للحفاظ على عمر البطاريات، دعها تنفذ تمامًا مرة كل 4 أشهر ثم قم بإعادة شحنها لمدة 4 ساعات.

#### الملحقات

##### لتركيب وفك الملحقات (الشكل A)

- يجب التأكد من أن الجهاز في وضعية الإيقاف قبل تركيب أو فك الملحقات.
- للتركيب، ضع الملحق الذي ترغب به على الجهاز وقم بلف الملحق في اتجاه عقارب الساعة لوضعه في مكانه.
- لفك، قم بتدوير الملحق عكس اتجاه عقارب الساعة حتى ينفصل ثم ارفعه.

##### تركيب الأمشاط الموجهة المثبتة وفكها

##### لتركيب

- اشبك الجزء الأمامي من المشط الموجه من على أسنان شفرة التشذيب العريضة.
- اضغط على ظهر المشط الموجه لأسفل إلى أن تسمع نقرة دلالة على تثبيته في مكانه.

##### للإخراج

- ارفع الفتحة على ظهر المشط الموجه إلى أعلى حتى تتحرر من رأس التشذيب العريض.

##### تركيب المشط القابل للضبط وفكه

- للتركيب، قم بمحاذاة القضبان الموجودة على المشط مع الفتحات الموجودة على جانبي ماكينة الحلاقة وحرك المشط لأسفل داخل ماكينة الحلاقة.
- للتعديل، اضغط على زر التعديل مع الاستمرار في الضغط عليه على ظهر المشط وحرك المشط إلى أعلى وأسفل. توقف عن الضغط على الزر لتثبيت المشط في موضعه. يتحدد طول القص وفق المقاييس الموجود على رأس جهاز التشذيب.

## تعليمات الاستخدام

- قم بتمشيط لحيتك أو شاربك دائماً بمشط ناعم قبل بدء التشذيب.
- قم بتمشيط شعرك في اتجاه نموه بحيث تكون الشعرات في أقصى ارتفاع لها وفي نفس الاتجاه.
- بعد التشذيب، قم بتحريك رقاقة ماكينة حلاقة على المناطق المشذبة للحصول على تشطيب ناعم ونظيف.
- وبما أن جميع الشعر لا ينمو في نفس الاتجاه، قد ترغب في تجربة تشذيب مواضع مختلفة (أي صعوداً أو نزولاً أو من جانب لآخر) لتحقيق أفضل النتائج.
- يجب أن يكون الشعر جافاً وخالياً من أي مواد شمعية أو لوشن.
- في حالة تراكم الشعر أثناء الاستخدام، أوقف تشغيل الوحدة، وقم بفك الملحق المستخدم وتنظيف قصاصات الشعر الزائد من الملحق وماكينة الحلاقة.

## 3 أيام بمظهر اللحية الخفيفة الجذابة، والحفاظ على شعر الجسم عند مستوى معين

الملحقات
جهاز التشذيب العريض مع المشط المثبت 1.5 ملم

## للحصول بمظهر اللحية الخفيفة الجذابة لمدة 3 أيام:

1. اترك اللحية تنمو حتى طول معين أطول قليلاً من الطلة التي تحاول الحصول عليها.
1. قم بتركيب المشط المثبت 1.5 ملم على ملحق التشذيب العريض.
2. مرر ملحق التشذيب على اللحية عكس اتجاه نمو الشعر.
3. قم بتنظيم وضبط أطراف اللحية الخفيفة باستخدام ملحق التشذيب الدقيق.
- لمزيد من التحكم في طول اللحية الخفيفة، يمكنك استخدام المشط القابل للضبط، وتشذيب اللحية باتجاه الأسفل بزيادات بداية من الطول الأكبر وصولاً إلى الطلة التي ترغب في الحصول عليها.

## الحفاظ على شعر الجسم عند مستوى معين: قم بتشذيب الشعر وصولاً إلى الطول المناسب

1. اقم بتركيب ملحق شعر الجسم.
2. من الممكن تشذيب شعر الجسم في 3 أطوال مختلفة (3 و 6 و 9 ملم). اختر الطول الذي ترغب فيه عن طريق تمرير المشط إلى واحد من الفتحات الثلاث الموجودة على جانب الملحق.
3. ضع الجانب المسطح من الملحق على البشرة.
4. ضع الجزء العلوي المسطح من الشفرة على الجلد، واسحب ببطء الشعر عكس اتجاه نمو الشعر.
5. استخدم حركات ضغط خفيفة ومحدومة.

## قص الشعر

الملحقات
رأس التشذيب العريض مع المشط القابل للضبط

**الخطوة 1- خلف الرقبة (الفقا)**

1. قم بتركيب رأس التشذيب العريض والمشط القابل للضبط.
2. اضبط المشط القابل للضبط على الطول الذي ترغب فيه.
3. أمسك المقص مع جعل أسنان الشفرة تشير لأعلى. ابدأ من وسط الرأس عند قاعدة الرقبة.
4. ارفع المقص ببطء ودعه يعمل خلال الشعر لأعلى وللخارج ويقوم بالتشذيب قليلاً في كل مرة.

**الخطوة 2 - خلف الرأس**

- قم بقص الشعر الموجود خلف الرأس باستخدام مشط الدليل الملحق 12 ملم أو 18 ملم.

**الخطوة 3 - جانب الرأس**

1. قم بتعديل المشط إلى إعدادات الطول الأقصر في المناطق المحيطة بالأذنين.
2. قم بزيادة إعدادات الطول على المشط القابل للضبط للانتقال تدريجياً إلى طول الشعر الموجود على جانب الرأس وصولاً إلى أطول شعر في أعلى الرأس.

**الخطوة 4 - أعلى الرأس**

- قم بتعديل المشط إلى إعدادات الطول الأكبر (حتى 20 ملم) ثم قم بقص الشعر على أعلى الرأس عكس اتجاه نمو الشعر الطبيعي.

**تشذيب السوالف**

لتشذيب السوالف، قم بتعديل المشط إلى إعدادات الطول الذي ترغب في الحصول عليه، أو استخدم أحد الأمشاط الموجهة الثابتة.

**تشذيب اللحية القصيرة/الطويلة**

الملحقات
رأس التشذيب العريض مع المشط القابل للضبط
رأس التشذيب الدقيق

1. قم بتركيب رأس التشذيب العريض والمشط القابل للضبط.
2. اضبط المشط القابل للضبط على الطول الذي ترغب فيه.
3. ابدأ التشذيب تحت الذقن على طول خط الفك.
4. توجه إلى أعلى باتجاه الأذن وخط اللحية العلوي.
5. قم بضبط حواف اللحية باستخدام ملحق التشذيب الدقيق.

**تحديد الحواف وقص الشعر الدقيق**

الملحقات
رأس التشذيب العريض

**تحديد الحواف:**

1. احمّل الجهاز بحيث يكون نصل (أسنان) القص مواجهة لك بزاوية 90 درجة على البشرة.
2. ابدأ بحافة اللحية/خط الشارب مع جعل الشفرات تستريح برفق على جلدك واستخدم حركات بطيئة بتحكم عال للحصول على خطوط محددة.

**قص الشعر الدقيق:**

1. استخدم أصابع يد واحدة لرفع الشعر عند قاعدة رأسك إلى أعلى بعيدًا عن العنق.
2. ينبغي أن تغطي سبابتك جذور الشعر الذي تقوم برفعه لتجنب قصه بطريقة الخطأ.
3. أمسك جهاز التشذيب عند قاعدة العنق بحيث تكون الشفرة متجهة لأعلى. حرك جهاز التشذيب أعلى العنق حتى يلمس أصبع السبابية الذي يحمي رؤوس الشعر.
4. حرك جهاز التشذيب ببطء مع إبقاء جذور الشعر عند قاعدة رأسك بعيدًا عن طريق جهاز التشذيب.

**التشذيب التفصيلي لشعر الأنف والأذن والحاجب**

الملحقات
ملحق تشذيب شعر الأنف والأذن والحاجب

**الأنف والأذن:**

1. قم بتركيب ملحق تشذيب شعر الأنف والأذن والحاجب.
  2. أدخل الملحق برفق في فتحة الأنف أو الأذن.
  3. حرك المرفق إلى الداخل والخارج مع لف جسم ماكينة الحلاقة في ذات الوقت.
- لا تدخل الملحق لمسافة تزيد على 6 ملم.
  - اغسل الملحق بعد كل استخدام.

**الحاجب:**

1. مرر الملحق برفق للتخلص من أي شعيرات طويلة أو شاردة عن الحاجب.
2. للتخلص من الشعر بالكامل، اجعل الملحق يلامس البشرة ثم حرك الجهاز على المنطقة التي ترغب بها.

**تشذيب اللحية الخفيفة والتشذيب عالي الدقة**

الملحقات
رأس التشذيب الدقيق

**تشذيب اللحية الخفيفة:**

- يحتوي ملحق جهاز التشذيب الدقيق على تكنولوجيا حلاقة التشذيب والتي تعمل على تشذيب الشعر حتى طول 0.2 ملم للحصول على طلة الشعر الخفيف الصغير.
1. قم بتركيب رأس التشذيب الدقيق.
  2. احمل الملحق بحيث يلامس الموجه على الطرف السفلي من النصل البشرة (تمامًا كما تحمل موس الحلاقة المبلل). الموجه الموجود على الحافة السفلية من النصل يساعد على تمدد الجلد أثناء التشذيب.
  3. استخدم حركات مماثلة لتلك التي تستخدمها في الحلاقة المبللة.



**التشذيب الدقيق:**

1. احمل ملحق التشذيب الدقيق بحيث يكون عمودياً على البشرة.
2. حركه نحو شعر الذقن أو بعيداً عنه للحصول على النتيجة التي ترغب بها. استخدم حركات ضغط خفيفة ومحدومة.

**رأس فرشاة التنظيف العميق**

الملحقات
رأس فرشاة التنظيف العميق

1. قم بترطيب شعيرات الفرشاة تحت ماء جاري. ملاحظة: لا تستخدم رؤوس الفرش عندما تكون جافة تماماً فقد يسبب ذلك تهيج الجلد.
  2. قم بترطيب جلدك بالماء وضع منظفاً على جلدك. أو ضع المنظف على الفرشاة مباشرة.
  3. نوصي بالتنظيف باستخدام فرشاة التنظيف العميق في 3 أقسام:
    - المنطقة (1) T، الجانب الأيمن (2) والجانب الأيسر (3).
  4. قم بتشغيل المنتج بتحريك مفتاح التشغيل/الإيقاف لأعلى.
  5. ضع فرشاة التنظيف على جلدك مباشرة.
  6. يرجى تحريك الفرشاة برفق على الجلد واللحية بحركات دائرية لتجنب منطقة العين الحساسة.
- ملاحظة: حاول عدم الضغط بشدة على الفرشاة عندما تكون على الجلد مباشرة.

**الحصول على حواف الحلاقة النظيفة**

الملحقات
رأس ملحق ماكينة حلاقة الرقاقة

1. أمسك جهاز التشذيب بحيث تلامس الرقاقة الصغيرة وجهك برفق.
2. استخدم حركات ضرب قصيرة.
- ملاحظة: ماكينة الحلاقة ذات الشاشة الصغيرة مصممة لحلاقة المناطق التفصيلية الصغيرة. وليست مصممة لحلاقة الأسطح الكبيرة.

**صيانة أداة التشذيب الخاصة بك**

قم بصيانة المنتج لضمان أداء طويل الأمد. وننصحك بتنظيف المقص بعد كل استخدام.

**بعد كل استخدام**

- قم بإزالة أي شعر متراكم من جهاز الزينة ورؤوس الملحق.
- أسهل وأكثر طريقة صحية لتنظيف جهاز الزينة هي فصل الرأس عن جسم جهاز الزينة وشطف الرأس بماء دافئ.
- يجب عدم شطف جسم جهاز الزينة.
- ضع فطرة أو فطرتين من زيت قاطع أو زيت ماكينة خياطة على الشفرات.
- قم بتشغيل المقص لتوزيع الزيت بالتساوي وامسح أي زيت زائد.


## إخراج البطاريات

نوصي بشدة بأن يقوم فني متخصص بإخراج البطارية القابلة للشحن. يوجد لدى بعض من عبوات ماكينة الحلاقة والأدوات أطراف حادة وقد تسبب الإصابة في حالة عدم التعامل معها على نحو صحيح.

- يجب إخراج البطارية القابلة للشحن من الجهاز قبل التخلص منها.
- افصل محول الشحن قبل إزالة البطارية.
- 1. تحقق من إفراغ شحن البطارية بالكامل. للقيام بذلك، قم بتشغيل ماكينة الحلاقة حتى تتوقف.
- 2. افصل الجهاز.
- 3. باستخدام أداة مناسبة، قم بفصل النصفين الأمامي والخلفي من العبوة عند الخط الفاصل.
- 4. قم بفك المسمارين اللذان يثبتان الغلاف الداخلي الشفاف إلى النصف الخلفي من العبوة الخارجية.
- 5. ارفع العبوة الداخلية.
- 6. اسحب حامل الموتور الأسود خارج العبوة الشفافة.
- 7. أخرج الدائرة الكهربائية والبطارية من العبوة الداخلية الشفافة.
- 8. اقطع الأسلاك التي تثبت لوحة الدائرة في اللوحة الكهربائية.
- تخلص من البطارية بشكل صحيح.

## إعادة التدوير

لتجنب المشاكل البيئية والصحية الناجمة عن المواد الخطرة، يجب عدم التخلص من الأجهزة، والبطاريات القابلة لإعادة الشحن والبطاريات غير القابلة لإعادة الشحن التي تحمل علامة واحدة من هذه الرموز مع نفايات البلدية غير المصنفة. يجب دائمًا التخلص من المنتجات الكهربائية والإلكترونية، وكذلك إذا أمكن، البطاريات القابلة لإعادة الشحن وغير القابلة لإعادة الشحن، في نقطة رسمية مناسبة لإعادة التدوير/جميع المخلفات.



## الخدمة والضمان

سيتم تصحيح العيوب التي تؤثر على وظائف المنتج التي تظهر خلال مدة الضمان بالاستبدال أو الإصلاح وفقًا لخيارنا بشرط استخدام المنتج والحفاظ عليه وفقًا للتعليمات.

لا تتأثر حقوقك القانونية.

يتم استبعاد المواد الاستهلاكية.

لا يتم تغطية العيوب الناجمة عن الإصلاح بواسطة موزع غير معتمد.

إذا طلبت مركز الخدمة، يرجى أن يكون لديك رقم الموديل فلن نكون قادرين على مساعدتك دون ذلك. ويمكن العثور على رقم الموديل على لوحة مقنن الجهاز.

اطلب ضمانك الإضافي لمدة 1 سنة بتسجيل منتجك على الإنترنت. فقط اذهب لموقع:

[www.remington-europe.com/register/](http://www.remington-europe.com/register/)





**Ref. No. PG6000**

**Type No. PG05A**

20/UK/ PG6000 T22-7001152-B Version 04 /20

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.

Spectrum Brands (UK) Ltd

Fir Street,

Failsworth,

Manchester

M35 0HS

[www.remington.co.uk](http://www.remington.co.uk)

© 2020 Spectrum Brands, Inc.