Russell Hobbs®

A BRITISH ICON SINCE 1952

Opulence Ovenware

Please retain instructions for future reference.

BEFORE FIRST USE
Hand-wash thoroughly.

USING THE OVENWARE
Suitable for domestic oven use only, up to 220 °C.
Do not use metal utensils.

CLEANING AND STORING THE COOKWARE
Always allow to cool before cleaning. This ovenware is not dishwasher safe. Hand-wash using a mild detergent and nonabrasive sponge, rinse and dry thoroughly.

CAUTION
Always use heat-resistant oven gloves to move the ovenware. Never expose hot ovenware to cold liquid. If there is any evidence of damage to the ovenware, dispose of it carefully.

Dimensions stated are approximate internal measurements taken rim to rim. If this product proves unsatisfactory or if you have any further queries, please contact your retailer.

Made in China.
Distributed by:
Spectrum Brands Australia Pty Ltd – 11B Chifley Drive, Mentone, VIC, 3194.
Spectrum Brands New Zealand Ltd – Level 1, 8 Hugo Johnston Drive, Penrose, Auckland, 1061.
Supplied by:
Ultimate Products UK Ltd., Victoria Street, Manchester OL9 0DD. UK under licence from Spectrum Brands (UK) Limited. Russell Hobbs is the registered trademark of Spectrum Brands (UK) Limited.

www.russellhobbs.com.au
www.russellhobbs.co.nz

Subject to care and use instructions being followed, the Russell Hobbs 5-Year warranty promises to replace, substitute or refund any product that fails due to faulty workmanship or materials. This 5-year warranty does not cover any damage caused by accident or misuse and is in addition to your statutory rights. The warranty does not cover scratches to the coating, or discolouration of the coating as a result of overheating or ageing. Should any defects due to faulty workmanship or materials appear within the warranty period, please return the goods with proof of purchase to the retailer.

AUS: For full warranty details, visit www.russellhobbs.com.au/cookware-kitchenware-warranty.
NZ: For full warranty details, visit www.russellhobbs.co.nz/cookware-kitchenware-warranty.