

CHILE
GARANTIA

REMINGTON®

Póliza de Garantía

DECLARACIONES: al artículo que usted acaba de adquirir, ha sido diseñado y construido con la más avanzada tecnología Remington y sometido a un estricto control de calidad. Recomendamos leer cuidadosamente el manual de uso, en el cual se indica el plazo de vigencia de esta garantía antes de usar su nuevo producto.

Para leer más de su GARANTÍA:

- * Deberá presentar esta tarjeta. En caso que ella no esté fechada y firmada al momento de la compra, deberá ser acompañada de la factura o factura de su compra.
- * Antes que nada lea que el artículo al cual concierne el producto está en buenas condiciones.
- * Si se cubren las indicaciones que hay en el producto que podría causar daños y peligros.
- * Si el producto después de seguir todas las instrucciones de manual, no funciona correctamente, comuníquese a nuestro número de atención al cliente.

Ficha de Garantía

Producto: _____

Modelo: _____

Nº de Serie: _____

Lugar de Compra: _____

Fecha de Compra: _____

Boleta: _____

Datos Consumidor

Nombre: _____

Dirección: _____

Ciudad: _____

Teléfono: _____

Atención al Cliente

(56-2) 5713701

Atención al Cliente Remington Chile

Av. Los Andes 100, Santiago, Chile

Atención al Cliente Remington Chile

Atención al Cliente Remington Chile

Atención al Cliente Remington Chile

www.remington.cl

GARANTIA PARA PRODUCTOS REMINGTON
EN CENTRO AMERICA

RAYOVAC CENTRO AMERICA Garantiza este producto por un periodo de 2 años en todas sus partes, contra cualquier defecto de fabricación a partir de la fecha de compra.

CONDICIONES:
1. Para hacer efectiva esta garantía deberá presentar la nota de compra o factura correspondiente, junto con el producto en nuestras oficinas:

a. Guatemala
17 avenida 24-75 zona 11
C. Comercial Novicentro 2do Nivel. Local #37
Guatemala City, Guatemala
Tel. 1-800-Rayovac / Tel. (502) 2222-7200

b. El Salvador
Bldv. Merliot, Jardines de la Libertad Ciudad Merliot,
Santa Tecla
Apartado Postal 2079
El Salvador, C.A.
Tel. (503) 2278-9466

c. Honduras
Distribuidora Rayovac Honduras, S.A.
Boulevard Suyapa 100 metros al Norte de Emisoras
Unidas frente a Sears
Apartado Postal 499
Tegucigalpa, M.D.C. Honduras C.A.
Tel. (504) 231-3542

d. Costa Rica
Rayovac Costa Rica, S.A.
San Francisco de Dos Rios de la Bomba La Pacifica,
400 Este carretera a Curridabat,
San Jose Costa Rica
Apartado Postal 52-2010 Zapote
Tel. 506 2272 2242

e. Nicaragua
Fimportadora y Distribuidora Ocal, S.A.
Km 17 Carretera a Masaya
Tip Top Industrial, 300 metros al este
Nindirí, Masaya, Nicaragua
Tel. (505) 276-9400

2. RAYOVAC CENTRO AMERICA se compromete sustituir el producto por uno igual o similar, y a rembolsar al consumidor los gastos razonables de envío o transportación del producto.

3. RAYOVAC CENTRO AMERICA se compromete a cambiar el producto, si la falla es atribuible a defecto de fabricación. Durante los 30 días inmediatos posteriores a la compra del producto esta garantía se hace válida en la misma tienda en la que se adquirió el producto, presentando la presente garantía y la nota de compra o factura correspondiente. Después de ese tiempo deberá contactar a las oficinas de Rayovac a las direcciones antes mencionadas, presentando la presente garantía, la nota de compra o factura y el producto.

Esta garantía será nula en los siguientes casos:
1. Cuando el producto se hubiese utilizado en condiciones distintas a las normales.
2. Cuando el producto no hubiese sido operado de acuerdo con el instructivo de uso que se acompaña.
3. Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por

RAYOVAC CENTRO AMERICA
NOTA: En caso de extravío de la presente póliza de garantía, el consumidor puede recurrir a la tienda o proveedor para que se le expida otra póliza de garantía previa presentación a la nota de compra o factura.

Aparato: _____
Modelo: _____
Nombre y/o razón social del distribuidor. _____

Dirección y teléfono: _____
Fecha de Entrega: _____
Sello y Firma: _____

LA CORPORACION RAYOVAC NO SE RESPONSABILIZA POR NINGUN INCIDENTE, ESPECIALMENTE DEBIDO AL USO DE ESTE PRODUCTO. TODAS LAS GARANTIAS SON LIMITADAS A 2 AÑOS EMPEZANDO EN LA FECHA DE COMPRA.

Comentarios o sugerencias:
Visite www.ProductosRemington.com

© Marga registrada y TM marca comercial de Spectrum Brands, Inc. (SBI).


REPÚBLICA DOMINICANA
Rayovac Republica Dominicana S.A.
Prolongación Ave. Rómulo Betancourt Zona Industrial de Herrera
Santo Domingo, Republica Dominicana
Tel. (1-809) 530-5409
ECUADOR
Línea de servicio al cliente
593 2 326 1638
Quito-Ecuador

PANAMA
DISTRIBUIDORA J MALLOL E HIJOS
Parque Industrial Costa del Este
Teléfono: (507) 2715000
Ciudad de Panama-Panamá

VIDA PANAMA
Calle 16 Av Enriquez A Jimenez. Apartado Postal 0203-00535
Teléfono: (507) 4339000
Zona libre Colon-Panamá

PERU
Spectrum Brands del Peru S.A.C
Av. Angamos 2431, Torres de Limatambo,
San Borja, Perú
Telef. 511-225-1388

Importado por:
RAYOVAC ARGENTINA S.R.L.
Humboldt 2495 Piso #3
(C1425FUG) C.A.B.A. Argentina.
CUIT No: 30-70706168-1
Importador # 76983
Hecho en CHINA.



REMINGTON®

Use and Care Guide

S-7200

S-7220

Key Features:

- (A) Steam vents and channels
- (B) Advanced Ceramic plates infused with micro-conditioners— provide high, even heat for less frizz
- (C) Innovative LCD temperature display
- (D) Graphic heat setting indicator
- (E) Temperature adjustment.
- (F) Turbo boost function
- (G) Switch lock function
- (H) On/Off button
- (I) Hinge lock
- (J) Swivel cord

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING.

KEEP AWAY FROM WATER.

DANGER

As with most electrical appliances, electrical parts are electrically live even when switch is off. To reduce the risk of death by electric shock:

- Always unplug this appliance from the electrical outlet immediately after using.
- Do not use while bathing or in the shower.
- Do not place or store this appliance where it can fall or be pulled into a tub or sink.
- Do not place or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Unplug this appliance before cleaning it.
- Always store this appliance and cord in a moisture-free area. Do not store it in temperatures exceeding 140°F (60°C).
- This appliance is for household use only.
- Do not plug or unplug this appliance when your hands are wet.
- Do not use an extension cord.
- This appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the heated unit directly on any surface while it is hot or plugged in. Use the stand provided.
- The plug on this appliance has one blade wider than the other, it is a polarized plug. As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Do not attempt to defeat this safety feature.
- An appliance should never be left unattended when it is plugged in.
- This appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from the heated surfaces. Do not wrap the cord around the appliance.
- Never use while sleeping.
- Never drop or insert any object into any of the appliance's openings.
- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.

WARNING

To reduce the risk of burns, fire, electric shock or injury to persons:

- An appliance should never be left unattended when it is plugged in.
- This appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from the heated surfaces. Do not wrap the cord around the appliance.
- Never use while sleeping.
- Never drop or insert any object into any of the appliance's openings.
- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.

SAVE THESE INSTRUCTIONS

KEEP AWAY FROM CHILDREN

Thank you for purchasing this Remington® product. Please carefully read the instructions contained in this booklet, and keep them in a safe place for future reference.

How to Use

Unique steam vent and channel design: Unique steam vents and channels allow this styler to be safely used on wet or dry hair. The channels extract moisture from damp hair and allow steam to escape through the vents, drying hair and sealing the cuticle at the same time. Creates salon straight, shiny hair in less time, with less damage.

Ceramic: Ceramic protects against damaging hot spots with high, even heat to lock in moisture and create long-lasting styles.

2. Select appropriate temperature for your hair type using the controls on the side of the straightener.

Wet/Dry Setting
This Straightener can be used on wet or dry hair.

- Wet mode** – use on towel dried hair.
 - Towel dry hair well before styling.
 - Do not use on dripping wet hair.
 - When you turn on the straightener it will automatically set itself to wet mode. It will default to 200°C which is the minimum temperature required for Wet mode straightening.
 - Before using the straightener on wet hair ensure the straightener has fully heated to your desired temperature between 200°C - 230°C.
 - Select appropriate temperature for you hair type using the controls on the side of the straightener.
 - When straightening wet hair you will hear a hissing sound and the unit will steam. This is a good thing – it is the sound of excess water in your hair evaporating and this is not harmful to the condition of your hair.

Dry mode – use on dry hair

- Before use, ensure the hair is clean, dry and tangle-free.

Plate Temperature	Number of bars	Symbol	Hair Type
140°-160°C	1 bar		Very fine, fragile, damaged hair
170°-190°C	2 bars		Normal, easy to curl hair
200°-220°C (110V) 200°-230°C (220V)	3 bars		Thick, difficult to curl hair

Usage Tips

NOTE: Please see “Wet/Dry Setting” to the left.

Straightening Your Hair

- Gently towel dry hair to remove excess water. Avoid rubbing hair with a towel, as this creates split ends and frizziness. Detangle hair with a wide-toothed comb.
- Plug the styler into an electrical outlet. Push the on/off switch to turn the styler on. The indicator light will begin to glow.
- Adjust the temperature using the temperature buttons. The display will flash while the unit heats up, then glow steadily when it has reached the selected temperature. The unit will beep when ready.
- Divide hair into manageable sections and clip the upper layers on top of your head and out of the way. Work with the underneath layers first.
- Test the styler on a small section of hair, and then adjust the temperature up or down before styling the rest of your hair.

NOTE:

- If you find that you need a higher setting while styling your hair, simply adjust the dial to a higher number.
- While styling your hair, if you find that you need a lower temperature, adjust the dial to a lower heat setting.

- Take a small section of hair and comb through it with a fine-toothed comb. Pull hair down and away from your scalp, and hold it taut.
- Hold the straightener with the steam vents facing away from your scalp. Starting at the roots, clamp hair firmly between the plates and run the slyer down the entire hair strand, from root to

Cleaning
Make sure the unit is unplugged and cool. Use a damp cloth to clean the plates and the outside of the power handle. No other maintenance of the unit is required.

Storage
Unplug the unit whenever it is not in use. Allow it to cool, then store it out of reach of children in a safe, dry location.

Never wrap the cord around the appliance. This will cause the cord to wear prematurely and break, thus voiding the warranty. Handle the cord carefully and avoid jerking, twisting, or straining it, especially at plug connections.

Warranty

Limited Two-Year Warranty
Spectrum Brands, Inc. warrants this product against any defects that are due to faulty material or workmanship for a two-year period from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse, servicing by unauthorized persons, use with unauthorized accessories, connecting it to incorrect current and voltage, wrapping cord around appliance causing premature wear & breakage or any other conditions beyond our control.

KEEP ORIGINAL SALES RECEIPT AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.
No responsibility, obligation, or liability is assumed for the installation or maintenance of this product.

Electrical Characteristics:
S-7200
110V: 120V~ 60Hz 47W
220V: 120-240V~ 50-60Hz or 50/60Hz
S-7220
110V: 120V~ 60Hz 140W

Questions or comments:
Visit www.productosremington.com
© Registered Trademark and TM
Trademark of Spectrum Brands, Inc. (SBI).

© 2014 SBI
03/14 Job# CS2013-4-5_77_RevC
T22-0001320

Spectrum Brands, Inc.
Middleton, WI 53562

MADE IN CHINA