

REMINGTON®
style therapy



**PROTECT
& curl!**



CiF75

High protection ceramic 19mm tong



REMINGTON **PROTECT
& curl!**

High protection ceramic 19mm tong




ENGLISH

Thank you for buying your new Remington® product.
Before use, please read these instructions carefully and keep them in a safe place for future reference.



PRODUCT FEATURES

- A Professional 19 mm curling tong
- B Ceramic – high even heat no hot spots
- C Fabric covered barrel with TEFLON® surface protector - curls with kindness to prevent snagging and breakage. 
- D Instant high heat, ready in 60 seconds
- E On-off switch with LED indicator light – flashes until selected temperature has been reached. Press and hold for 2 seconds to switch on and off.
- F Variable high heat, 130°C - 180°C
- G Cool tip
- H Heat protection stand
- I Automatic safety shut off after one hour
- J Heat proof pouch
- K 2.5m swivel cable

3 year guarantee



INSTRUCTIONS FOR USE

- ▶ **Due to the extreme heat capabilities of this styler, extra care should be taken when using.**
- ▶ Before use, make sure hair is clean, dry and tangle-free. Clip-up hair ready for styling.
- ▶ Use approximately one inch sections of hair and place firmly under the tong clip.
- ▶ For tighter curls use smaller sections, for looser curls and waves use larger sections.

ENGLISH

- ▶ Wind hair around heated barrel. Allow approximately 10 seconds for curl to form.
- ▶ Unwind tong and depress the clip to release the curl.
- ▶ Allow hair to cool before styling.
- ▶ Do not scratch the surface, as this could tear the TEFLON® woven fibre.



CLEANING AND MAINTENANCE

- ▶ Ensure the unit is unplugged and cool prior to cleaning.
- ▶ Wipe clean any build up of styling products with a slightly damp cloth (do not scrub).
- ▶ **NOTE: Excessive use of styling products may deteriorate the TEFLON® woven fibre.**
- ▶ Do not use an abrasive cleaning fluid to clean, as damage will occur.



SAFETY CAUTIONS

WARNING – FOR ADDITIONAL PROTECTION THE INSTALLATION OF A RESIDUAL CURRENT DEVICE (RCD) WITH A RATED RESIDUAL OPERATING CURRENT NOT EXCEEDING 30mA IS ADVISABLE. ASK AN ELECTRICIAN FOR ADVICE.

WARNING – THIS APPLIANCE MUST NOT BE TAKEN INTO A BATHROOM. IT SHOULD NOT BE USED NEAR BATHTUBS, SHOWERS, BASINS OR OTHER VESSELS CONTAINING WATER OR OTHER LIQUIDS.

THE STYLER SHOULD BE UNPLUGGED FROM MAINS SUPPLY WHEN NOT IN USE.

- ▶ Do not leave the styler unattended when switched on.
- ▶ Allow the styler to cool down before storage.
- ▶ Do not immerse in water or other liquids.
- ▶ Do not place styler on soft material e.g. carpet, bedding, towels, rugs etc.
- ▶ Always ensure the voltage to be used corresponds to the voltage stated on the unit.*
- ▶ Keep this product out of reach of children. The use of this appliance by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge can give cause to hazards. Persons responsible for their safety should give explicit instructions or supervise the use of the appliance.
- ▶ Do not use any attachments with this styler, other than those supplied by Remington®.
- ▶ Avoid allowing any part of the hot plates to contact the face, neck or scalp.
- ▶ Do not wrap the cord around the unit. Check cord regularly for any sign of damage.
- ▶ Damaged cords can be dangerous. If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard.

ENGLISH

- ▶ Special tools are required for any examination, adjustment or repair. Unqualified repair work could lead to hazardous conditions for the user.
- ▶ We do not accept responsibility for damage to the product, persons or other items(s), caused by misuse, abuse or non-compliance with these instructions.
- ▶ This appliance is not intended for commercial or salon use.




WIRING INSTRUCTIONS UK Plugs Only

This product is fitted with a BS1363 plug fused at 13A. If the plug is unsuitable, it should be disconnected and an appropriate plug fitted as detailed below. If it is necessary to replace the plug fuse, use only fuses that are approved to BS1362, rated at 13A. If in doubt consult a qualified electrician.

The wires in the mains lead are coloured in accordance with following code:

BLUE - NEUTRAL
BROWN - LIVE



As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:
The wire which is coloured BLUE must be connected to the terminal which is marked 'N' or coloured BLACK. The wire which is coloured BROWN must be connected to the terminal which is marked 'L' or coloured RED. Never connect either of the wires to the big EARTH terminal marked 'E' or coloured GREEN or GREEN AND YELLOW.



PROTECT THE ENVIRONMENT

Do not dispose of the product in household waste at the end of its life. Disposal can take place at the Remington® Service Centre or appropriate collection sites.



For further information on recycling see www.remington-europe.com

ENGLISH



SERVICE AND WARRANTY

This product has been checked and is free of defects. We warrant this product against any defects that are due to faulty material or workmanship for the warranty period from the original date of consumer purchase. If the product should become defective within the warranty period, we will repair any such defect or elect to replace the product or any part of it without charge provided there is proof of purchase. This does not mean an extension of the warranty period.

In the case of a warranty simply call the Remington® Service Center in your region. This warranty is offered over and above your normal statutory rights.

The warranty shall apply in all countries in which our product was sold via an authorised dealer.

This warranty does not include damage to the product by accident or misuse, abuse, alteration to the product or use inconsistent with the technical and/or safety instructions required. This warranty shall not apply if the product has been dismantled or repaired by a person not authorised by us.



This product is not suitable for use in bath or shower.



REMINGTON® SERVICE HOTLINE

United Kingdom

 **+44 0800 212 438 (free call)**

Rayovac Europe Ltd,
Watermans House, Kingsbury Crescent,
The Causeway, Staines, Middlesex,
TW18 3BA, UNITED KINGDOM

www.remington.co.uk



Model No. CiF75

I0/UK/CiF75 Version 04/10 Part No. T22-29972

REMINGTON® is a Registered Trade Mark of Spectrum Brands, Inc.,
or one of its subsidiaries

VARTA Consumer Batteries GmbH & Co. KGaA

Alfred-Krupp-Str.9

73479 Ellwangen

Germany

www.remington-europe.com

© 2010 SBI

TEFLON® is a registered trademark of E.I. du Pont de Nemours
Company and is used under license by Spectrum Brands.

This product is not suitable for use in bath or shower.

