

REMINGTON®

PROluxe Rollers



H9100


Register online for
£10,000 prize draw
EXTRA year guarantee
FREE rewards gallery



Visit www.remington.co.uk/product/register
You must register within 28 days
of purchase.

Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe.
Remove all packaging before use.

IMPORTANT SAFEGUARDS

- 1 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
- 2 Do not leave the appliance unattended while plugged in.
- 3 Warning: Do not use this appliance near bathtubs, showers, basins or other vessels containing water. 
- 4 Warning - for additional protection the installation of a residual current device (RCD) with a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask an electrician for advice.
- 5 For UK, Household Use Only. Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the dryer/straightener is not permitted (see BS7671).
- 6 When storing away, wrap the cord around the unit. Check the cord regularly for any sign of damage.
- 7 If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard.
- 8 Do not use the appliance if it is damaged or malfunctions.
- 9 Do not allow the roller to touch the face, neck or scalp.
- 10 Only set the appliance down on a heat-proof surface.
- 11 Do not place the appliance on any soft furnishings.
- 12 Do not use attachments not recommended by Remington®.
- 13 This appliance is not intended for commercial or salon use.
- 14 Let the appliance cool down before cleaning and storing away.
- 15 Always keep the lid closed while the rollers are heating.
- 16 Ensure the rollers and heated clips are correctly placed on the heated rails not against the heated rail.
- 17 Do not use on artificial hairpieces or wigs.



KEY FEATURES

- 1 Velvety flocked rollers:
8 x medium 25mm
12 x large 32mm
- 2 Ceramic heated hinged clips
- 3 Cool touch ends
- 4 On indicator light
- 5 Base unit

PRODUCT FEATURES

- Ceramic rollers with ionic conditioning for long lasting results.
- Dual heating technology heats rollers and clips.
- Sets curls in 5 minutes with long lasting results.
- Ceramic heated hinge clips with grip tech finish - helps to secure the hair in place.
- Fast heat up - ready in 90 seconds.

INSTRUCTIONS FOR USE

- Before use, ensure the hair is clean, dry and tangle-free.
- For extra protection use a heat protection spray.
- ✱ Hairsprays contain flammable material - do not use while using this product.
- Section the hair prior to styling. Style the lower layers first.
- Plug the product into the mains power supply.
- The on indicator light will glow once plugged in indicating that the rollers are on.
- ✱ CAUTION: the appliance will begin to heat-up as soon as the power supply is switched on.
- The lid should remain closed until the rollers are ready to use.
- Rollers will be ready in approximately 90 seconds. Allow 3 to 5 minutes for best results.
- When you feel your setters are ready, open the lid for 1 minute and begin use.

✱ TO CURL

- 1 Starting with the lower sections of hair, take a section the width of a roller.
 - 2 Start by using the medium sized rollers. Slide the roller up out of the base unit using the clip.
 - 3 Remove the clip from the roller.
 - 4 With the section of hair in one hand and the roller in the other, place the roller at the ends of the hair and wind the hair around the roller towards the root ensuring the hair is always taut.
 - 5 Secure the hair in place using the clip.
 - 6 Repeat steps 3-5 until all of your hair is in rollers.
 - 7 Let the hair cool for approximately 5-10 minutes to achieve long lasting styles.
- ✱ For best results ensure the large rollers are used on the top sections of hair.

- 8 Whilst the hair is cooling, unplug the rollers from the mains and allow to cool.
- 9 When you feel ready, remove the rollers from the hair, hold the roller in one hand and remove the clip with the other.
- 10 Gently and slowly unwind the hair from the roller.
- 11 Once the roller is removed from the hair, place the clip onto the roller and store back in the base unit.
- 12 Repeat this process until all rollers are removed.
- ★ Once all rollers are removed, gently tease out the curls with your hand or a brush for a more natural finish.
- 13 Once the unit has cooled, wrap the cord around the unit and store away.

CARE FOR YOUR ROLLERS

- Unplug the appliance and allow to cool.
- Wipe all the surfaces with a damp cloth.
- Don't use harsh or abrasive cleaning agents or solvents.



ENVIRONMENTAL PROTECTION

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol must not be disposed of with unsorted municipal waste, but recovered, reused or recycled.



SERVICE AND GUARANTEE

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.

Your statutory rights are not affected.

Consumables are excluded.


Defects from repair by an unauthorized dealer are not covered.


If you call the Service Centre, please have the Model No. to hand, as we won't be able to help you without it. The Model No. can be found on the rating plate of the appliance.

Replacement parts and accessories are available to buy at www.remington.co.uk/parts-accessories

➔ SERVICE CENTRE

United Kingdom

 Tel 0800 212 438 (free call mainland UK)

 +44 161 947 3111 (call outside the UK)

Spectrum Brands (UK) Ltd

Fir Street, Failsworth, Manchester

M35 0HS, UK

www.remington.co.uk

Ireland

 Tel 142 951 40

Remington Consumer Products,

Unit B12, Ballymount Corporate Park,

Ballymount, Dublin 12.

www.ie.remington-europe.com

REGISTER ONLINE FOR

£10,000 prize draw, EXTRA year guarantee, FREE rewards gallery.

Visit www.remington.co.uk/productregister. You must register within 28 days of purchase.

Model No. H9100

17/UK/ H9100 T22-0004498 Version 01 / 17

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.
Spectrum Brands (UK) Ltd

Fir Street,

Failsworth,

Manchester

M35 0HS

www.remington.co.uk

© 2017 Spectrum Brands, Inc.