REMINGTON®


Pro Big Curl Tong



CI5338







Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

WARNING: This appliance is hot. Keep out of reach of children at all times.

IMPORTANT SAFEGUARDS

- This appliance can be used by children aged from 8 years and above and
 persons with reduced physical, sensory or mental capabilities or lack of
 experience and knowledge if they have been supervised/instructed and
 understand the hazards involved. Children shall not play with the
 appliance. Cleaning and user maintenance shall not be done by children
 unless they are older than 8 and supervised. Keep the appliance and cable
 out of reach of children under 8 years.
- Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- When the appliance is used in a bathroom, unplug it after use since the
 proximity of water presents a hazard even when the applaince is switched
 off
- For additional protection, the installation of a residual current device (RCD)
 having a rated residual operating current not exceeding 30 mA is advisable
 in the electrical circuit supplying the bathroom*.
 - * Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the appliance is not permitted in the UK (see BS7671).
- Burn hazard. Keep the appliance out of reach from young children, particularly during use and while cooling down.
- Never leave the appliance unattended when it is connected to the power supply.
- Always place the appliance with its stand, if any, on a heat-resistant, stable flat surface

- If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard
- Do not allow any part of the appliance touch the face, neck or scalp.
- Keep the power plug and cord away from heated surfaces.
- Do not use attachments other than those we supply.
- Do not use the appliance if it is damaged or malfunctions.
- Do not twist or kink the cable, or wrap it round the appliance. Check the cord regularly for any sign damage.
- This appliance is not intended for commercial or salon use.

PARTS

- 1. 38mm barrel with 4 x protection
- coating
 2. Tong Clip
- 3. On-off button
- 4. Temperature controls

- Ready light
- 6. Cool tip
- 7. Stand
- 8. Swivel cord

ADDITIONAL FEATURES

- Fast heat up—ready to use in 30 seconds.
- Automatic safety shut off this unit will switch itself off if no button is pressed or it is left on after 60 minutes.
- Multivoltage: for home or abroad. At 120V times and temperatures may vary.

INSTRUCTIONS FOR USE

- Before use, ensure the hair is clean, dry and tangle-free.
- Section the hair prior to styling. Style the lower layers first.
- Plug the product into the mains power supply.
- 2. Press and hold the on/off button to switch on.
- Select the appropriate temperature for your hair type using the "+" and "-" temperature controls. Start styling on lower temperatures first.
- The "+" button will increase the temperature and the "-" button will decrease the temperature.

Recommended Temperatures

Temperature	Hair type
Low setting	Thin / fine, damaged or bleached hair
Medium setting	Normal, healthy hair
High setting	Thick and difficult to style hair

Caution: the hottest temperatures should only be used by experienced stylers.

- 5. The indicator light will stop flashing once the desired temperature is reached.
- Place a section of hair under the long tong clip (smaller sections create tighter curls, larger sections create large curls or waves).
- 7. Turn the styler to roll the hair around the barrel
- 8. Wait about 10 seconds for the curl to form.
- 9. Unwind the tong and release the curl.
- 10. Repeat this around the head to create as many curls as desired.
- After use, press and hold the off button for 2 seconds to turn off then unplug the appliance.
- Let the appliance cool before cleaning and storing away.
- **Tip**: let the curls cool before styling or brushing; this will help to prolong the curls.

CLEANING AND MAINTENANCE

- · Unplug the appliance and allow to cool.
- · Wipe all the surfaces with a damp cloth.
- Don't use harsh or abrasive cleaning agents or solvents.

RECYCLING



To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/collection point.

SERVICE AND GUARANTEE

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.

Your statutory rights are not affected.

Consumables are excluded.

Defects from repair by an unauthorized dealer are not covered. If you call the Service Centre, please have the model number to hand, as we won't

be able to help you without it. The model number can be found on the rating plate of the appliance.

Replacement parts and accessories are available to buy at www.remington.co.uk/parts-accessories

SERVICE CENTRE

United Kingdom

Tel 0800 212 438 (free call mainland UK)

+44 161 947 3111 (call outside the UK)

Spectrum Brands (UK) Ltd Fir Street, Failsworth, Manchester M35 0HS, UK

www.remington.co.uk

Ireland

Tel 142 951 40
Remington Consumer Products,
Unit B12, Ballymount Corporate Park,
Ballymount, Dublin 12.
www.ie.remington-europe.com

Ø REGISTER ONLINE FOR

£10,000 prize draw, EXTRA year guarantee, FREE rewards gallery.

Visit www.remington.co.uk/productregister. You must register within 28 days of purchase.

Model No CI5338

© 2018 Spectrum Brands, Inc.

18/UK/ CI5338 T22-7000301 Version 04 /18
Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.
Spectrum Brands (UK) Ltd
Fir Street,
Failsworth,
Manchester
M35 0HS
www.remington.co.uk