
# REMINGTON®

# **Keratin Protect Wand**




**CI83V6** 



Register online for £10,000 prize draw EXTRA year guarantee FREE rewards gallery





Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

WARNING: This appliance is hot. Keep out of reach of children at all times.

## IMPORTANT SAFEGUARDS

- This appliance can be used by children aged from 8 years and above and
  persons with reduced physical, sensory or mental capabilities or lack of
  experience and knowledge if they have been supervised/instructed and
  understand the hazards involved. Children shall not play with the
  appliance. Cleaning and user maintenance shall not be done by children
  unless they are older than 8 and supervised. Keep the appliance and cable
  out of reach of children under 8 years.
- Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- When the appliance is used in a bathroom, unplug it after use since the
  proximity of water presents a hazard even when the applaince is switched
  off
- For additional protection, the installation of a residual current device (RCD)
  having a rated residual operating current not exceeding 30 mA is advisable
  in the electrical circuit supplying the bathroom\*.
  - \* Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the appliance is not permitted in the UK (see BS7671).
- Burn hazard. Keep the appliance out of reach from young children, particularly during use and while cooling down.
- Never leave the appliance unattended when it is connected to the power supply.
- Always place the appliance with its stand, if any, on a heat-resistant, stable flat surface

- If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard
- Do not allow any part of the appliance touch the face, neck or scalp.
- Keep the power plug and cord away from heated surfaces.
- Do not use attachments other than those we supply.
- Do not use the appliance if it is damaged or malfunctions.
- Do not twist or kink the cable, or wrap it round the appliance. Check the cord regularly for any sign damage.
- This appliance is not intended for commercial or salon use.
- WARNING: Contains traces of nuts.

## PARTS

- 19-28mm advanced ceramic barrel infused with Keratin and Almond Oil
- 2. On/Off switch
- 3. Temperature controls
- 4. Digital temperature display
- 5. Pro+ setting

- 6. Cool tip
- 7. Stand
- 8. Swivel cord
- 9. Heat resistant glove (not shown)
- 10. Heat resistant pouch (not shown)

## **ADDITIONAL FEATURES**

- Fast heat up—ready to use in 30 seconds.
- Automatic safety shut off this unit will switch itself off if no button is pressed or it is left on after 60 minutes.
- Multivoltage: for home or abroad. At 120V times and temperatures may vary.

## INSTRUCTIONS FOR USE

- Before use, ensure the hair is clean, dry and tangle-free.
- Section the hair prior to styling. Style the lower layers first.
- Use the heat resistant glove to avoid any accidental burns.
- 1. Plug the product into the mains power supply.
- 2. Press and hold the on button to switch on.
- 3. Select the desired temperature.
- Start styling on lower temperatures first. Set the desired temperature using the +
  and buttons. The "+" button will increase the temperature and the "-" button will
  decrease the temperature.

## **Recommended Temperatures**

Temperature	Hair type
150°C - 175°C	Thin / fine, damaged or bleached hair
175°C - 195°C	Normal, healthy hair
195°C - 210°C	Thick and difficult to style hair

**Caution**: the hottest temperatures should only be used by experienced stylers.

- The selected temperature will flash continuously until the desired temperature is reached.
- Working on one section at a time, hold the handle with the barrel facing down and wrap a section of hair around the heated barrel.
- 8. Wait about 10 seconds for the curl to form, then unwind the hair to release the curl.
- Repeat this process around the head to create as many curls as desired.
   TIP: Let the curls cool before further styling or brushing, this will help to prolong the curls.
- 10. After use, press and hold the off button to turn off then unplug the appliance.

#### PRO+ Setting

 To activate the PRO+ setting, press and hold the "+" button for 2 seconds. This will select a temperature of 185°C for healthier styling. PRO+ will appear on the digital display.

## **CLEANING AND MAINTENANCE**

- Unplug the appliance and allow to cool.
- Wipe all the surfaces with a damp cloth.
- · Don't use harsh or abrasive cleaning agents or solvents.

## RECYCLING



To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/collection point.

## **SERVICE AND GUARANTEE**

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.

Your statutory rights are not affected.

Consumables are excluded.

Defects from repair by an unauthorized dealer are not covered.

If you call the Service Centre, please have the model number to hand, as we won't

if you can the service Centre, please have the model number to hand, as we won to be able to help you without it. The model number can be found on the rating plate of the appliance.

Replacement parts and accessories are available to buy at www.remington.co.uk/parts-accessories

## SERVICE CENTRE

## **United Kingdom**

Tel 0800 212 438 (free call mainland UK)

+44 161 947 3111 (call outside the UK)

Spectrum Brands (UK) Ltd Fir Street, Failsworth, Manchester M35 0HS, UK www.remington.co.uk

#### Ireland

Tel 142 951 40
Remington Consumer Products,
Unit B12, Ballymount Corporate Park,
Ballymount, Dublin 12.
www.ie.remington-europe.com

## **Ø** REGISTER ONLINE FOR

£10,000 prize draw, EXTRA year guarantee, FREE rewards gallery.

Visit www.remington.co.uk/productregister. You must register within 28 days of purchase.

## Ref. No. CI83V6

18/UK/ CI83V6 T22-7000097 Version 01 /18 CI83V6

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.

Spectrum Brands (UK) Ltd Fir Street,

Failsworth.

Manchester

M35 0HS

www.remington.co.uk

© 2018 Spectrum Brands, Inc.