

Read the instructions and keep them safe. If you pass the appliance on, pass on the instructions too. Remove all packaging, but keep it till you know the appliance works.

### important safeguards



Follow basic safety precautions, including:

- 1 This appliance must only be used by or under the supervision of a responsible adult.
- 2 The appliance is not a toy. Don't let children play with it.
- 3 Don't put the appliance in liquid, don't use it in a bathroom, near water, or outdoors.
- 4 Store the appliance away from direct sunlight, and, if possible, from fluorescent light.
- 5 Don't run the motor for more than 1 minute, or it may overheat. After 1 minute, switch off for at least 3 minutes, to let the motor cool.
- 6 Don't use the appliance for any purpose other than those described in these instructions.
- 7 Don't run the appliance empty, it may overheat.
- 8 Don't use the appliance if it's damaged or malfunctions.



### household use only





#### dismantling

- 1 Turn the mill round so that you can see the rear.
- 2 Grip the cover in one hand, and the grinder in the other.
- 3 Turn the cover to move the pointer ▼ from  to .
- 4 Lift the cover off.

#### fitting batteries



- 1 Fit 4 R6/LR6 (AA) batteries into the motor unit.
- 2 The polarities (+ and -) are marked on the battery compartment.

#### fill the grinder

- 1 Lift the motor unit off the grinder.
- 2 Fill the grinder with peppercorns, sea salt, dried herbs or spices.
- 3 Don't overfill, or it won't fit together.
- 4 Align the pointers ▼ ▼ on the bottom of the motor unit with the padlocks   on the top of the grinder, and lower the motor unit on to the grinder.
- 5 The spindle should slide easily into the centre of the motor unit.
- 6 Lower the cover on to the motor unit.
- 7 Align the pointer ▼ on the cover with the open padlock , push the cover down, then turn it to align the pointer ▼ with the closed padlock .

#### adjust the grind

- 1 Turn the whole mill upside down, and turn the knob right (→) till it won't go any further.
- 2 Now turn it left (←) a little.
- 3 Turn the mill right way up, and press and release the switch.
- 4 Check the grind size, and adjust till it's the way you want it.
- 5 Don't turn it more than 6 complete turns towards +, or you may unscrew the knob from the spindle.
- 6 Set the base down and sit the mill on the base.
- 7 Do the same for the other mill.



## care and maintenance

Wipe the outside of the mills with a clean dry cloth. Don't let them get wet or damp, and don't use detergent.

## bulb replacement

- 1 The bulb is wire-ended, in a plastic housing.
- 2 You need to remove the housing from the underside of the mill.
- 3 Turn the whole mill upside down.
- 4 Grip the plastic surrounding the bulb, and pull it straight up.
- 5 You'll feel some initial resistance, then it'll come out
- 6 Align the wires in the replacement bulb with the contacts inside the socket underneath the mill, and push the replacement bulb fully into the socket.

## battery care

- 1 Check that the batteries are fitted correctly – there's a guide inside the battery compartment.
- 2 Don't leave dead batteries in the appliance, they may leak caustic gunge over the product and surroundings.
- 3 Unless you're using the batteries regularly, it's best to remove them altogether.
- 4 When you need new batteries, change them all. Don't use new and used batteries together.
- 5 Don't use different kinds of batteries together (they should all be carbon-zinc, or all alkaline).
- 6 Don't put old batteries in a fire or incinerator.
- 7 Don't try to recharge batteries unless they're specifically designed to be recharged.

## service

The product isn't user-serviceable. If it's not working, read the instructions, check the batteries. If it's still not working, consult your retailer. If that doesn't solve the problem:

Pack carefully, with a note of your name, address, day phone number, and what's wrong. If under guarantee, say where and when purchased, and include proof of purchase (till receipt). Send it to Customer Returns (address below right).

### Customer Service

(correspondence only)  
Salton Europe Ltd  
Failsworth  
Manchester  
M35 0HS

### Customer Returns

Salton Europe Ltd  
Heath Mill Road  
Wombourne  
Wolverhampton  
WV5 8AQ

Customer Service ([service@saltoneurope.com](mailto:service@saltoneurope.com))  
telephone 0845 658 9700 (local rate number)

## guarantee

Defects affecting product functionality appearing within one year of purchase will be corrected by replacement or repair provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. Documentation, packaging, and product specifications may change without notice.

## wheelie bin symbol

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol mustn't be disposed of with unsorted municipal waste, but recovered, reused, or recycled.

