



Russell
Hobbs

RHVS1CAN_IB_FA_120313

SEAL FRESH VACUUM CANISTERS

RHVS1CAN

Congratulations on the purchase of your new Russell Hobbs vacuum canisters. Each unit is manufactured to ensure safety and reliability. Before using these items for the first time, please read the instructions carefully and keep it for future reference. Pass it on if you pass on the items. When using the vacuum canisters, basic safety precautions should always be followed.

NOTE: All warranty and detailed instructions for this product can be found in the Instruction booklet for the Russell Hobbs Seal Fresh Vacuum Sealer RHVS1

IMPORTANT: Only the Seal Fresh Vacuum Sealer RHVS1 supplied by Russell Hobbs can be used with the vacuum canisters RHVS1CAN



1. Canister lid
2. Canister
3. Seal/Open dial
4. Hose Port
5. Hose

BEFORE FIRST USE

- Unpack your canisters.
- Remove all packaging material and any stickers from the product.
- As some parts may be packed separately, check to ensure all items have been unpacked before disposing of the packaging.
- Wash all removable parts as instructed in the “CARE AND CLEANING” section of this manual.

IMPORTANT: Do not submerge the canister lids in water, refer to the “CARE AND CLEANING” section of this manual for full cleaning instructions.

- Dry thoroughly before use.

INSTRUCTIONS

ABOUT YOUR SEAL FRESH VACUUM CANISTERS

1. Place the items to be vacuumed sealed into the canister and leave at least 2.5cm of space between the food/items and the cover rim.
2. Ensure the canister cover rim and canister gasket seal are completely clean.
3. Place the canister lid on the canister
4. Open the vacuum sealer unit lid and place the larger end of the hose (provided with the canisters) into the air intake in the vacuum chamber area securely. Place the smaller end of the hose into the hose port on the canister lid. Ensure the Seal/Open dial on canister lid is turned to the Seal position.

CAUTION: If the sealing strip has been activated in the same vacuum sealing session, do not touch, it becomes hot.

5. Press the canister switch (just above the air intake) to start vacuuming. To ensure there is no air leaking between the cover and the canister, at the beginning of the vacuuming use your hand to push the dial down. The vacuuming will stop automatically when enough vacuum pressure is achieved.
6. Hold the canister lid down securely when you pull out the end of the hose. Ensure you hold the dial in the seal position then rotate the end of the hose counter-clockwise while lifting it out of the lid.
7. Your canister can be stored in the pantry, fridge and freezer, depending on the items packaged.

OPENING THE CANISTER AFTER VACUUM PACKAGING

1. In order to open the canister, you need to release the air first by turning the Seal/Open dial clockwise from Seal to Open.
2. Now that the air is released, simply pull off the lid.

CARE AND CLEANING

1. Canister bases (not lids) are top rack dishwasher safe. Alternatively wash the canister bases in warm water with a mild dishwashing soap.
2. Canister lids can be wiped down with a damp cloth. Do not immerse in water.
3. Wash the canister hose in warm water with a mild dishwashing soap.
4. Ensure the accessories are dried thoroughly before re-using.
5. Canisters are freezer safe.

TROUBLE SHOOTING

The canister will not vacuum:

1. Make sure the hose adaptor is firmly connected both to the appliance and the canister.
2. Check if the knob of the canister to ensure it is set to the Seal position.
3. Check if there is any damage or cracks in the canister or lid, if yes, change it for a new one.
4. Check the function of the vacuum sealer.
5. Make sure the rim of the canister is clean.

If all the above situations are excluded, please contact customer service.

www.russellhobbs.com.au
www.russellhobbs.co.nz

RUSSELL HOBBS and logo are Trade Marks of Spectrum Brands, Inc., or one of its subsidiaries.

©2013 Spectrum Brands, Inc.