



# Russell Hobbs®

A BRITISH ICON SINCE 1952

## Opulence Cutlery Set

Please retain instructions for future reference.

### **BEFORE FIRST USE**

Hand-wash and dry thoroughly.

### **CLEANING THE CUTLERY**

Hand-wash only. Do not use harsh or abrasive cleaners or scourers. Not safe for dishwasher use. Make sure cutlery is thoroughly dry before storing. To improve the longevity of the plated cutlery, occasional use is recommended.

### **KEEP OUT OF THE REACH OF CHILDREN**

Made in China.

Distributed by:

Spectrum Brands Australia Pty Ltd – 11B Chifley Drive, Mentone, VIC, 3194.

Spectrum Brands New Zealand Ltd – Level 1, 8 Hugo Johnston Drive, Penrose, Auckland, 1061.

Supplied by:

Ultimate Products UK Ltd., Victoria Street, Manchester OL9 0DD.

UK under licence from Spectrum Brands (UK) Limited. Russell Hobbs is the registered trademark of Spectrum Brands (UK) Limited.

[www.russellhobbs.com.au](http://www.russellhobbs.com.au)

[www.russellhobbs.co.nz](http://www.russellhobbs.co.nz)

Subject to care and use instructions being followed, the Russell Hobbs 2-Year warranty promises to replace, substitute or refund any product that fails due to faulty workmanship or materials. This 2-year warranty does not cover any damage caused by accident or misuse and is in addition to your statutory rights. Should any defects due to faulty workmanship or materials appear within the warranty period, please return the goods with proof of purchase to the retailer.

**AUS:** For full warranty details, visit  
[www.russellhobbs.com.au/cookware-kitchenware-warranty](http://www.russellhobbs.com.au/cookware-kitchenware-warranty).

**NZ:** For full warranty details, visit  
[www.russellhobbs.co.nz/cookware-kitchenware-warranty](http://www.russellhobbs.co.nz/cookware-kitchenware-warranty).