

# REMINGTON®

EST. NEW YORK 1937

## S2 SILKY SERIES LADY SHAVER KIT

**USE & CARE  
MANUAL**

PLEASE READ  
PRIOR TO USE



To register your product go to  
[www.remington-products.com.au](http://www.remington-products.com.au)  
[www.remington.co.nz](http://www.remington.co.nz)

**2 YEAR WARRANTY**

**WF2000AU**

## **IMPORTANT SAFETY INSTRUCTIONS**

**When using electrical appliances, basic precautions should always be observed, including the following.**

### **READ ALL INSTRUCTIONS BEFORE USING**

**DANGER: As with most electrical appliances, electrical parts are electrically live even when the switch is off.**

**For additional protection, the installation of a residual current device (rcd) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.**

**WARNING: To reduce the risk of burns, electrocution and fire or injury to persons:**

- The appliance should never be left unattended when plugged into a power outlet, except when charging the appliance.
- This appliance should not be used by children or other persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep the appliance and the charging cable away from the edge of table or countertops and out of reach of children and persons with reduced physical, sensory or mental capabilities.
- This appliance is not a toy. Children shall be supervised to ensure they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Never operate this appliance if it has a damaged cord or plug, if it is not working correctly or if it has been dropped or damaged. If the supply cord or plug of the appliance is damaged it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. It cannot be repaired. Keep the cord away from heated surfaces.
- Charge, use and store the product at a temperature between 0°C and 32°C.
- Do not use outdoors or where aerosol (spray) products are being used, or where oxygen is being administered.

- Do not use this appliance with damaged or broken foils or cutters, as injury may occur.
- Do not plug or unplug the appliance with wet hands.
- For household use only.
- Do not place or store the appliance or charging adaptor where it can fall or be knocked into a sink or bath.
- Do not place in or drop the charging adaptor into water or any other liquid.
- If an appliance falls into water, “unplug it” immediately. Do not reach into the water.
- Unplug the charging adaptor from the electrical outlet immediately after fully charging.
- Unplug and switch off this appliance before cleaning it.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments not recommended by Remington.
- Never drop or insert any object into any opening of this appliance.
- Always store the appliance and charging adaptor in a moisture-free location.
- Do not use on people who are asleep.
- Do not use an extension cord or a voltage converter with this appliance.
- Do not wrap the cord around the appliance.

**WARNING:** For charging the battery, only use the adaptor supplied with the appliance.

This appliance should be charged by approved safety isolating adaptors SW-047010AU (AUS version) with the outlet capacity of 4.7Vdc 100mA (adaptor output).

Remington strongly recommends that an approved Safety Switch (residual current device) be installed to protect all bathroom power outlets. Ask an electrical contractor for advice.

**SAVE THESE INSTRUCTIONS**

## WF2000AU S2 SILKY SERIES LADY SHAVER KIT

### Use & Care Instruction Manual

Thank you for purchasing your new Remington® S2 Lady Shaver. The model you have chosen is designed to provide a gentle, close shave.



### KEY PARTS

1. Shaving head
2. Head release button
3. Flexible outer foil
4. Massaging strip
5. Flexible trimmer
6. On/Off switch

#### Also Includes:

- Bikini Comb
- Exfoliating Glove
- Storage Bag
- Power Adaptor
- Cleaning Brush

## ABOUT YOUR SHAVER

WF2000AU SPECIFICATIONS	
Power System	Cordless (Rechargeable)
Full Charge Time	20 Hours
Cordless Shave Time	40 Minutes
Indicators	Charging
Massaging Strip	Yes
Voltage Type	100-240V
Adaptor	SW-047010AUL

**Power System:** Cordless – shaver can only be used without the power cord.

**Charging Indicator:** Charging indicator light on the adaptor will light up when the shaver is being charged.

**Voltage Type:** Single Voltage – shaver can only be used with an outlet voltage of 100-240V.

### INSTRUCTIONS FOR CHARGING

Always ensure that your hands, shaver and charge stand are dry before charging.

Allow 20 hours for a complete charge. The charging indicator light on the adaptor will light up to indicate that your shaver is charging. One full charge allows 40 minutes of cordless usage time.

Use product until the battery is low. This is indicated by the shaver running distinctly slower. Your shaver cannot be overcharged, however, if the product is not going to be used for an extended time period (2-3 months), unplug it from the outlet and store. Fully recharge your shaver when you would like to use it again.

## **Charging Cautions:**

- Do not attach the power adaptor to the outlet with wet hands.
- Always charge the shaver in a cool, dry place.
- Do not charge the shaver in close proximity to water.

## **HOW TO USE**

Your shaver is suitable for legs, underarms and the bikini area.

### **For Everyday Shaving**

1. Remove protective cap.
2. Turn the shaver on.
3. Hold the shaver at a right angle to your skin and move the shaver against the direction of the hair growth.
4. After shaving, turn shaver off.

Note: Before dry shaving, make sure that the area is clean, dry and free from creams or oils.

### **For Longer Hair**

If you have not shaved for a while, use the flexible trimmer before shaving. This will help you achieve a more effective shaving result:

1. Turn shaver on.
2. Hold the shaver with the trimmer facing your leg and slightly tilted towards you (approximately at a 45° angle).
3. Move the trimmer slowly against the direction of the hair growth.
4. After shaving, turn shaver off.

### **Trimming and Shaping**

1. Attach the bikini comb.
2. Turn the shaver on.
3. Hold the shaver at a right angle to your skin and press down gently.
4. Edge and shape the area as desired.
5. After shaving, turn shaver off.

## **FOR BEST SHAVING PERFORMANCE**

We recommend that you use your new shaver daily for two or three weeks to allow time to find the optimum shaving methods for your particular type of hair growth patterns.

### **Caution:**

If your skin is easily irritated by shaving, or you suffer from skin allergies, you should test a section of your arm or leg before using the shaver.

Note: Rinse only with cool or warm water, not hot water. Do not rinse with water hotter than 70°C.

## **CLEANING & MAINTENANCE**

### **Care For Your Shaver**

To ensure long lasting performance of your shaver, clean the head assembly regularly. The easiest and the most hygienic way to clean the shaver is by rinsing the shaving head after use with warm water. Always keep the protective headguard on the shaving head when the shaver is not in use.

### **After Each Use**

1. Ensure the shaver is turned off.
2. Press the release buttons to open the shaver head.
3. Blow on the foils to remove any loose debris.
4. Brush or rinse the accumulated hair from the main body of the shaver, shaving head and cutter assembly.
5. Leave the head assembly open to let the shaver dry completely.
6. Return the shaving head to its original position and snap in place.

### **Note:**

- Ensure that the shaver is turned off when cleaning.
- Do not clean the shaving foils with the brush.
- At regular intervals, put a drop of sewing machine oil onto the foils and cutters heads.

**PLEASE USE BLOCK LETTERS**

**\* INDICATES REQUIRED INFORMATION**

**\*NAME:**

**\*ADDRESS:**

[illegible]

**\*CITY:**

**\*STATE:**

\*POSTCODE:

**\*POSTCODE:**


**\*CONTACT NUMBER:**

AREA  
CODE

Ph:

[illegible]

**\*PAYMENT INSTRUCTIONS:**

☐ I enclose my cheque/money order (make payable to Spectrum Brands Australia Pty Ltd or Spectrum Brands New Zealand Limited)

**OR**

☐ Please charge this purchase to my credit card account: ☐ Mastercard ☐ Visa

Card Number

Expiry Date


CARD HOLDER NAME:

ADDRESS:

CITY:

STATE:


SIGNATURE:

POSTCODE:




# ACCESSORY ORDER

For replacement parts and accessories contact customer service

For help or to place an order on the phone  
call Remington Customer Service:

- ① Australia: 1800 623 118 (toll free)
- ① New Zealand: 0800 736 776 (toll free)

**REMINGTON®**  
EST. NEW YORK 1937

Remington is a Registered Trademark  
of Spectrum Brands, Inc., or one  
of its subsidiaries.

## MONEY BACK OFFER – AUSTRALIA / NEW ZEALAND ONLY

If within 60 days you are not fully satisfied with your Remington® shaver, just return the shaver with this completed coupon and a copy of your Australian/New Zealand purchase receipt to Remington®. In return, we will send you a cheque for the full purchase price of the shaver. Please allow 6-8 weeks for your cheque to arrive.

Name:

Address:

City:

State:  Postcode:  DOB:

Contact No: Area Code:  Ph:

Product Model number:

Is this the first Remington shaver you have owned/purchased? Yes ☐ No ☐

Why are you returning this shaver?

Skin Irritation ☐ Shave is not close enough ☐ Takes too long to shave ☐

Other:

**REMINGTON®**  
EST. NEW YORK 1937

**Spectrum Brands Australia Pty Ltd**

Locked Bag 3004  
Braeside, VIC 3195  
AUSTRALIA

Customer service in Australia: 1800 623 118  
E-mail: [consumer.enquiry@remington-products.com.au](mailto:consumer.enquiry@remington-products.com.au)  
Website: [www.remington-products.com.au](http://www.remington-products.com.au)

**Spectrum Brands New Zealand Limited**

PO Box 9817  
Newmarket, Auckland 1149  
NEW ZEALAND

Customer service in New Zealand: 0800 736 776  
E-mail: [info@remington.co.nz](mailto:info@remington.co.nz)  
Website: [www.remington.co.nz](http://www.remington.co.nz)



## REPLACING THE FOILS & CUTTERS

Signs that your foils and cutters need replacing:

**Irritation:** As foils get worn, you may experience skin irritation.

**Pulling:** As the cutters wear, your shave may not feel as close and you may feel your cutter pulling on your hair.

**Wear:** You may notice that the cutters have worn through the foils.

To ensure the continued highest quality performance from your shaver, we recommend that foils and cutters are replaced every 6 months.

### To Replace The Foil

Note: Ensure the shaver is switched off.

1. Remove the shaver head.
2. Gently push the small plastic tabs area at either end of the foil carrier. The foil carrier should then easily detach from the shaving head.
3. To reassemble, snap the new foil carrier into position.
4. Attach the shaving head.


#### Caution:

- Only hold the plastic to prevent damage to the foil.
- Do not press on the foil when replacing.

### To Replace The Cutters:

Note: Ensure the shaver is switched off.

1. Open the shaving head.
2. To remove cutter, grasp cutter between thumb and forefinger and pull upward.
3. To reassemble cutter, place cutter onto oscillator tip. Gently push down clicking into position.



## BATTERY DISPOSAL




Note: The battery is not intended to be removed or replaced under normal use. The only time the battery should be removed or the unit opened or disassembled, is at the end of the product's useful life before it is discarded.

- The WF2000AU shaver contains a NiMH (Nickel Metal Hydride) battery. Once the shaver has reached the end of its life, to ensure proper disposal of the product, please take the appliance to a recycling centre, where the internal rechargeable battery should be removed by a professional and recycled separately.
- For more information about recycling of electrical and battery operated appliances, please contact your local council office or your household waste disposal service.

**Caution:** Do not put in the fire or mutilate your batteries when disposing as they may burst and release toxic materials. Do not short circuit as it may cause burns.

### How to Remove the Batteries from the WF2000AU (See diagrams to right)

1. Remove screw from bottom of shaver.
2. Separate top and bottom housings.
3. Unscrew and remove inner frame.
4. Open the inner housing and remove the batteries.
5. Insulate battery ends by (1) placing each battery individually into separate plastic bags or (2) covering the terminals of each battery completely with plastic or nonconductive electrical tape.



## DISPOSAL/RECYCLING

Legislation in some localities mandates that e-waste (anything with a plug, battery or cord) is disposed of through controlled recycling facilities and must not be disposed of in general household waste. For more information about recycling of electrical and battery operated appliances, please contact your local council or your local household waste disposal service.



**This product is not suitable to use in a bath or shower.**

This product conforms to radio frequency interference requirements.

Any product purchased and used commercially carries a limited 90 Day Warranty.

# Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Limited

## WARRANTY AGAINST DEFECTS

In this warranty:

**Australian Consumer Law** means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

**CGA** means the New Zealand Consumer Guarantees Act 1993;

**Goods** means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

**Manufacturer, We or us** means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ACN, 007 070 573; or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Limited, as the case may be, contact details as set out at the end of this warranty;

**Supplier** means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

**You** means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for the period of two (2) years from the date of purchase (**Warranty Period**). If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

### Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Consumable parts (such as shaver heads, cutters and foils) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:
  - (a) Retain this warranty with your receipt/proof of purchase; and
  - (b) Return the Goods to us at the relevant address below or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
  - (a) Any serial number or appliance plate is removed or defaced;
  - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. A limited 90-day Warranty applies to any industrial or commercial use of the Goods. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Limited.

Contact us or the Supplier for further details.

#### **Spectrum Brands Australia Pty Ltd**

Locked Bag 3004

Braeside, VIC 3195

AUSTRALIA

Customer service in Australia: 1800 623 118

E-mail: [consumer.enquiry@remington-products.com.au](mailto:consumer.enquiry@remington-products.com.au)

Website: [www.remington-products.com.au](http://www.remington-products.com.au)

#### **Spectrum Brands New Zealand Limited**

PO Box 9817

Newmarket, Auckland 1149

NEW ZEALAND

Customer service in New Zealand: 0800 736 776

E-mail: [info@remington.co.nz](mailto:info@remington.co.nz)

Website: [www.remington.co.nz](http://www.remington.co.nz)

**REMINGTON®**  
EST. NEW YORK 1937

#### **REMINGTON SERVICE HOTLINE**

☎Australia 1800 623 118 (toll free)

☎New Zealand 0800 736 776 (toll free)

#### **AUTHORISED REPAIR CENTRES**

Visit [www.remington-products.com.au](http://www.remington-products.com.au) for Authorised repair centre details.

® Registered Trade Mark of Spectrum Brands Inc., (SBI) or one of its subsidiaries

© 2021 Spectrum Brands Inc.

Rev. 05/21

Part No. T22-7001961

Type: F02A

