

REMINGTON®

EST. NEW YORK 1937

PURE CONFIDENCE LADY SHAVER



**USE & CARE
MANUAL**

PLEASE READ
PRIOR TO USE

To register your product go to
www.remington-products.com.au
www.remington.co.nz

2 YEAR WARRANTY

WR1000AU

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be observed, including the following.

READ ALL INSTRUCTIONS BEFORE USING

DANGER: As with most electrical appliances, electrical parts are electrically live even when the switch is off.

For additional protection, the installation of a residual current device (rcd) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

WARNING: TO REDUCE THE RISK OF BURNS, ELECTROCUTION AND FIRE OR INJURY TO PERSONS.

- The appliance should never be left unattended when plugged into a power outlet, except when charging the appliance.
- This appliance should not be used by children or other persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and use maintenance shall not be made by children without supervision.
- Never operate this appliance if it has a damaged cord or plug, if it is not working correctly, if it has been dropped or damaged, or dropped into water. If the supply cord or plug of the appliance is damaged it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. It cannot be repaired.
- Keep the cord away from heated surfaces.
- Charge, use and store the product at a temperature between 0°C and 32°C.
- Do not use outdoors or where aerosol (spray) products are being used, or where oxygen is being administered.
- Do not use this appliance with damaged or broken tracks or cutters, as injury may occur.
- Do not plug or unplug the appliance with wet hands.
- For household use only.

- Do not place or store the appliance or charging adaptor where it can fall or be knocked into a sink or bath.
- Do not place in or drop into water or any other liquid.
- If an appliance falls into water, “unplug it” immediately. Do not reach into the water.
- Unplug the charging adaptor from the electrical outlet immediately after fully charging.
- Unplug the power adaptor from the appliance before cleaning the appliance in water.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments not recommended by Remington.
- Never drop or insert any object into any opening of this appliance.
- Always store the charging adaptor in a moisture-free location.
- Do not use on people who are asleep.
- Do not use an extension cord or a voltage converter with this appliance.
- Do not wrap the cord around the appliance.
- Remington strongly recommends that an approved Safety Switch (residual current device) be installed to protect all bathroom power outlets. Ask an electrical contractor for advice.

SAVE THESE INSTRUCTIONS

WR1000AU PURE CONFIDENCE LADY SHAVER

USE & CARE INSTRUCTION MANUAL

Thank you for purchasing your new Remington® Pure Confidence Lady Shaver. Inside this manual you will find tips on using and caring for your shaver.



KEY PARTS

1. On/Off Switch
2. Shaving Heads
3. 360° Pivoting Neck
4. LED Battery Indicators
5. Charging Pins
6. Massaging Brush

7. Brush Mount
8. Exfoliating Brush

Also Includes:

- Head Guard
- Storage Bag
- Cleaning Brush
- Power Adaptor

WR1000AU SPECIFICATIONS	
Power System	Cordless (Rechargeable)
Full Charge Time	4 Hours
Cordless Run Time	Up to 60 Minutes
Indicators	LED Battery Indicators
Voltage Type	Worldwide 100 - 240V
Replacement Head & Cutters	SPR-WR1000AU

Power System: The WR1000AU shaver can only be used without the power cord. The shaver will not run while it is charging.

LED Battery Indicators: Lights display the battery charge level

- **Low Charge:** Top LED light will glow solid red to indicate the shaver needs to be recharged. There is less than 5 minutes of run time remaining.
- **Charging:** Bottom LED light will glow solid green to indicate the battery is taking a charge.
- **Full Charge:** When fully charged the green LED light will go off.

Worldwide Voltage: Shaver automatically adapts to an outlet voltage between 100V and 240V.

Note: Some countries will require the use of a plug adaptor that is not included with your shaver.

CHARGING

1. Plug power cord adaptor into the shaver.
2. Plug the adaptor into the wall outlet.
3. Fully charge your shaver for 4 hours before its first use. This first charge is important to the shaver's battery life.

Note: During the initial charge ignore the electronic indicators as they are in "Start Up Cycle".

Caution:

- Make sure the shaver and your hands are dry when charging the shaver.
- Always charge the shaver in a cool, dry place.

CHANGING THE ATTACHMENTS

1. The unit should be turned off when changing attachments.
2. Remove the attachments by lifting upward from the base.
3. Align the hexagon shapes of the base and brush mount and press to snap the brush mount onto the base.
4. Snap the massaging or exfoliating brush onto the brush mount.

MASSAGING BRUSH - PRE-SHAVE

Use the silicone massaging brush to exfoliate the skin and lift hairs for an extra close shave.

1. Dampen the silicon pre-shave massage brush.
2. Press On/Off button to turn on.
3. While applying gentle pressure, move the rotating brush in circular motions over the desired area.

EXFOLIATING BRUSH

1. Moisten the brush bristles by running under water.
2. Press On/Off button to turn on.
3. While applying gentle pressure, move the rotating brush in circular motions over the desired area.

SHAVING

1. Press power button to turn on.
2. Shave desired areas using short, circular strokes.
3. After shaving, turn the shaver off.

SHAVING TIPS WITH GEL OR FOAM (IN SHOWER OR OVER THE SINK)

Remington® Pure Confidence Lady Shaver is waterproof. You may use shaving foam or gel with your shaver. We recommend that you use the shaver in the shower for optimal performance.

1. Apply water to desired shaving area.
2. Apply shaving cream to desired shaving area.
3. Rinse shaver head under water.
4. Shave using short, circular strokes.
5. Throughout the shave, regularly rinse the shaver head under water to avoid residue build up.

6. When finished shaving, rinse shaved area.
7. Thoroughly rinse shaver head of all gel or foam.
8. Follow cleaning instructions.

Note: In order to ensure optimal performance, thoroughly rinse the shaver under water during and after shaving. This will avoid having the foam or gel dry in the cutting head and clogging the shaver.

SHAVING TIPS (DRY)

- Always hold the shaver at a right angle to the skin so that all three heads are touching the skin with equal pressure.
- Stretch skin with free hand so hairs stand upright, making it easier for them to enter the cutting chamber.
- Use moderate to slow, circular stroking movement.
- The use of short, circular motions in stubborn areas may obtain a closer shave.
- Do not press hard against the skin to avoid skin irritation and / or damage to the rotary heads.

CLEANING & MAINTENANCE

Note: When cleaning your shaver, make sure the shaver is turned off and disconnected from the power cord.


The shaver is a washable appliance. The head and body may be cleaned under warm water.

Caution:

- When cleaning the external surfaces of the shaver, do not use strong detergents or other chemicals.
- To dry, wipe the surface of the shaver with a dry towel. Do not use a hair dryer or heater to dry the shaver.

Note: The shaver head and neck assembly is designed to be detachable from the shaver body. Simply pull upwards from the neck of the shaver for easy release. To reattach the neck, align it with the neck attachment cavity so that it clips back into position.

Cleaning Your Shaver









SHAVER PARTS

- | | |
|---|---------------------------|
| 1. Head & cutter (hair pocket) assembly | 3. Neck assembly |
| 2. Detachment grooves | 4. Neck attachment cavity |

Daily Cleaning

1. Locate the detachment grooves on the head & cutter assembly. Gently pull to detach the hair pocket from the neck assembly (Diagram A).
2. Tap out excess hair shavings (Diagram B).
3. Rinse the head of the shaver in running water.
4. Gently reattach the hair pocket to the neck assembly until it locks in place on all three sides. The hair pocket may be reattached in any configuration (Diagram G).



PLEASE USE BLOCK LETTERS

* INDICATES REQUIRED INFORMATION

*NAME:

*ADDRESS:

*CITY:

*STATE: *POSTCODE:

*CONTACT NUMBER: AREA CODE Ph:

*PAYMENT INSTRUCTIONS:

☐ I enclose my cheque/money order (make payable to Spectrum Brands Australia Pty Ltd or Spectrum Brands New Zealand Limited)

OR

☐ Please charge this purchase to my credit card account: ☐ Mastercard ☐ Visa

Card Number

Expiry Date /

CARD HOLDER NAME:

ADDRESS:

CITY:

STATE:

POSTCODE:

SIGNATURE:

ACCESSORY ORDER FORM

Article		Part No.	Price each AUD	Price each NZD	Qty	Amount
Replacement Shaving Heads & Cutters for WR1000AU		SPR-WR1000AU	\$29.95 AUD	\$34.95 NZD		\$
Shaver Saver: Aerosol Spray Cleaner		SP4	\$11.95 AUD	\$14.95 NZD		\$
IMPORTANT: Pricing in effect at time of publication, inclusive of GST. Subject to change without notice. Postage & handling \$7.50 standard for Australia & New Zealand.						\$
						\$ 7.50
						\$

For help or to place an order on the phone
call Remington Customer Service:

- ① Australia: 1800 623 118 (toll free)
- ① New Zealand: 0800 736 776 (toll free)

REMINGTON®
EST. NEW YORK 1937

Remington is a Registered Trademark
of Spectrum Brands, Inc., or one
of its subsidiaries.



MAIL YOUR ORDER FORM TO:

AUSTRALIAN RESIDENTS:

Spectrum Brands Australia Pty Ltd
Chifley Business Park
1 Chifley Drive
Mentone, Victoria, 3194
Australia

NEW ZEALAND RESIDENTS:

Spectrum Brands New Zealand Pty Ltd
PO BOX 9817
Newmarket, 1149, Auckland
New Zealand

MONEY BACK OFFER – AUSTRALIA / NEW ZEALAND ONLY

If within 90 days you are not fully satisfied with your Remington® shaver, just return the shaver with this completed coupon and a copy of your Australian/New Zealand purchase receipt to Remington®. In return, we will send you a cheque for the full purchase price of the shaver. Please allow 6-8 weeks for your cheque to arrive.

Name:

Address:

City:

State: Postcode: DOB:

Contact No: Area Code: Ph:

Product Model number:

Is this the first Remington shaver you have owned/purchased? Yes ☐ No ☐

Why are you returning this shaver?

Skin Irritation ☐ Shave is not close enough ☐ Takes too long to shave ☐

Other:



Spectrum Brands Australia Pty Ltd
Locked Bag 3004
Braeside, VIC 3195
AUSTRALIA
Customer service in Australia: 1800 623 118
E-mail: consumer.enquiry@remington-products.com.au
Website: www.remington-products.com.au

Spectrum Brands New Zealand Limited
PO Box 9817
Newmarket, Auckland 1149
NEW ZEALAND
Customer service in New Zealand: 0800 736 776
E-mail: info@remington.co.nz
Website: www.remington.co.nz

Weekly Cleaning

1. Perform the Daily Cleaning steps 1 and 2.
2. Remove the hair pocket from the head & cutter assembly (Diagram A). Place the body of the shaver aside.
3. Slide the blue cutter support frame upwards towards the direction of the two cutters to release it from the assembly (Diagram C).
4. Lift and remove the cutter support frame away from the cutters.
5. Remove the cutters (Diagram D).
6. Thoroughly rinse away any debris from inner and outer cutters with warm water.
7. Replace the inner cutters (Diagram E).
8. Hold the cutter support frame with the raised centre section facing upwards. Place it over the cutters so that the centre mouth opening is facing the bottom cutter. Slide the cutter carrier downwards until the locking tab locks under the centre triangle (Diagram F).
9. Lubricate each cutter with Remington Shaver Saver (SP4).
10. Gently reattach the hair pocket to the neck assembly until it locks in place on all three sides. The hair pocket may be reattached in any configuration (Diagram G).

REPLACING SHAVING HEADS & CUTTERS

Please refer to the specifications' table on page 5 of this manual that lists the correct replacement part number for your shaver.

It is very important to replace the shaving heads and cutters when necessary to ensure a close, comfortable shave without irritation. We recommend they be replaced every 12 months. Here are some signs of head and cutter wear, indicating that replacement is needed:

- **Irritation:** As the heads get excessively worn you may experience some skin irritation. This would be especially noticeable when you apply moisturising lotion.
- **Pulling:** When the cutters wear you may feel a sense of pulling and a loss of closeness when you shave. This is an indication that it is time to replace the shaving heads and cutters.

Replacement heads & cutters may be obtained from your local retailer, or directly from Remington®. Simply fill out the attached accessory order form or alternatively your order can be processed over the phone via the Remington® Service Hotline - refer to page 16.

BATTERY DISPOSAL

Note: The battery is not intended to be removed or replaced under normal use. The only time the battery should be removed or the unit opened or disassembled, is at the end of the product's useful life before it is discarded.

- The WR1000AU contains a lithium-ion battery. Once the shaver has reached the end of its life, to ensure proper disposal of the product, please take the appliance to a recycling centre, where the internal rechargeable battery should be removed by a professional and recycled separately.
- For more information about recycling of electrical and battery operated appliances, please contact your local council office or your household waste disposal service.

Caution: Do not put in the fire or mutilate your batteries when disposing as they may burst and release toxic materials. Do not short circuit as it may cause burns.

We suggest you use local waste management centres to recycle this product at end of life.



Suitable for use in bath and shower.

This product conforms to radio frequency interference requirements.

Any product purchased and used commercially carries a limited 90 Day Warranty.

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Limited

WARRANTY AGAINST DEFECTS

In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

CGA means the New Zealand Consumer Guarantees Act 1993;

Goods means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ACN, 007 070 573; or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Limited, as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for the period of two (2) years from the date of purchase (**Warranty Period**). If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Consumable parts (such as shaver heads, cutters and foils) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:
 - (a) Retain this warranty with your receipt/proof of purchase; and
 - (b) Return the Goods to us at the relevant address below or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
 - (a) Any serial number or appliance plate is removed or defaced;
 - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. A limited 90-day Warranty applies to any industrial or commercial use of the Goods. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Limited.

Contact us or the Supplier for further details.

Spectrum Brands Australia Pty Ltd

Locked Bag 3004

Braeside, VIC 3195

AUSTRALIA

Customer service in Australia: 1800 623 118

E-mail: consumer.enquiry@remington-products.com.au

Website: www.remington-products.com.au

Spectrum Brands New Zealand Limited

PO Box 9817

Newmarket, Auckland 1149

NEW ZEALAND

Customer service in New Zealand: 0800 736 776

E-mail: info@remington.co.nz

Website: www.remington.co.nz

REMINGTON®
EST. NEW YORK 1937

REMINGTON SERVICE HOTLINE

①Australia 1800 623 118 (toll free)

②New Zealand 0800 736 776 (toll free)

AUTHORISED REPAIR CENTRES

Visit www.remington-products.com.au for Authorised repair centre details.

® Registered Trade Mark of Spectrum Brands Inc., (SBI) or one of its subsidiaries

© 2019 Spectrum Brands Inc.

Rev. 09/19

Part No. T22-7001234

Type: R16A



PLEASE
RECYCLE