





Russell Hobbs



instructions





error messages:

Lo = low battery

- = negative weight (interference)

0-Ld = overload (above 5kg)



Read the instructions and keep them safe. If you pass the scale on, pass on the instructions too. Remove all packaging, but keep it till you know the scale works.

important safeguards

Follow basic safety precautions, including:

- 1 This scale must only be used by or under the supervision of a responsible adult.
- 2 The scale isn't a toy. Don't let children play with it.
- 3 Don't put the scale in water or any other liquid, and don't use it anywhere damp or wet.
- 4 Store the scale away from direct sunlight, and, if possible, from fluorescent light.
- 5 Don't use the scale for any purpose other than those described in these instructions.
- 6 Don't use the scale if it's damaged or malfunctions.



household use only



fitting batteries

- 1 Turn the scale upside down.
- 2 Press the latch, to release the battery compartment cover.
- 3 Fit 2 CR2032 batteries in the battery compartment.
- 4 The positive (+) side of one battery should be underneath, and the positive (+) side of the other should be on top.
- 5 Replace the battery compartment cover.
- 6 Turn the scale right way up.
- 7 Switch on – if nothing happens, you've put the batteries in the wrong way round. There's no harm done, just swap them over.

positioning

- 8 Sit the scale on a stable, level surface.
- 9 Vibration and air movement will affect its accuracy.

switch on





- 10 Press the  button to switch the display on.
- 11 The display will go through a self test routine, then settle at zero.
- 12 To swap units between grams (g) and ounces (oz), press and hold the  button till the arrow moves to the unit you want.

- 13 The scale will remember this setting till you change it, or till you remove/replace the batteries.



weighing

- 14 Put the item to be weighed in the centre of the scale.
15 The display will change, then stabilise to show the correct weight.

tare

- 16 Press  to zero the display, so you can weigh the next ingredient.
17 Use this function to deduct the weight of the container, or the weight of existing ingredients:
a) Put the bowl on the scale.
b) Wait till its weight is displayed.
c) Press  – wait till the display stabilises at zero.
d) Add the first ingredient, and wait till its weight is displayed.
e) Press  – wait till the display stabilises at zero.
f) Add the next ingredient, and wait till its weight is displayed.
g) Press  – wait till the display stabilises at zero.
h) Repeat till you've weighed all the ingredients.
18 The scale is limited to 5kg. If you exceed this weight, the display will show "0.00".
19 If you put a bowl on the scale before switching on, it'll ignore its weight, so you can start measuring your ingredients from zero.

switching off

- 20 Press the  button to switch the display off.
21 If you don't use it for 2 minutes, it'll switch itself off. Pressing  will switch it on again.

battery care

- 22 Don't leave dead batteries in the scale, they may leak.
23 Unless you're using the scale regularly, remove the batteries.
24 Replace both batteries together, don't mix new and old ones.
25 Don't put old batteries in a fire or incinerator.
26 Don't recharge batteries unless they're designed to be recharged.
27 Don't put old batteries out with your normal household rubbish.
They must be disposed of in an environmentally friendly way.
Your local authority will have arrangements for their disposal.


care and maintenance

- 28 Clean the outside surfaces of the scale with a damp cloth.
- 29 Don't use harsh or abrasive cleaning agents or solvents.
- 30 Don't put the scale in water or any other liquid.
- 31 Don't put the bowl supplied with the scale in a dishwasher.

keyhole slot

- 32 You may use the keyhole slot to hang the scale up, out of the way, when not in use.

error messages (page 2)

- 33 If you see the low battery message, replace the batteries.
- 34 If the overload message shows, reduce the load.
- 35 The negative weight sign will show when you remove something from the scale. Press  to zero the display.
- 36 If the negative weight sign shows while weighing, something may be under the edge of the scale, interfering with it.
- 37 Interference from radio sources like mobile phones or microwave ovens may cause erratic operation. Switch off and move the scale.

recipes

We've got a couple of spare pages, so here are a few simple recipes.

classic Victoria sponge cake

- 100g butter/margarine
- 100g caster sugar
- 2 large eggs
- 100g self raising flour
- 1 drop vanilla essence

Grease two 180mm (7 inch) straight sided sandwich tins and line the bases with buttered greaseproof paper.

Beat the butter at medium to high speed till light and fluffy.

Reduce speed, and gradually add the eggs, then the vanilla.

Gradually add the flour, and turn the mixer up to medium speed once the ingredients start to incorporate.

Divide the mixture equally between the tins and level the surfaces.

Bake in the centre of a pre-heated oven at 180°C for about 25 minutes, then cool on a wire rack.

basic biscuits

- 100g plain flour
- 100g self raising flour
- 100g butter
- 150g caster sugar
- 1 medium egg
- 1 tsp vanilla essence

Cream the butter, sugar and vanilla essence till light, pale and fluffy.

Add the egg, then beat till everything has combined.

Sift the flours together then work them into the mixture.

Form into balls, put them on a greased baking tray, flatten them slightly, then bake in a pre-heated oven at 180°C for 12-15 minutes.

Cool on the tray for a few minutes, then move to a wire rack.

pizza dough (makes 2 large pizzas)

- 525g strong white flour
- 250ml water
- 1½ tbsp olive oil
- 1½ tsp dried yeast
- 1½ tsp sugar
- 1½ tsp salt

Sift the flour into a bowl and add the yeast, sugar and salt. Add the water and oil and mix till the dough is fully incorporated and smooth in texture.

Cover the bowl with a damp tea towel or cling film and let it rest in a warm place for about half an hour.

Remove the dough and knead for a few minutes, till it's smooth and elastic.

Cut the dough in half, roll out into circles on a floured surface and put them on a non-stick baking sheet or a pizza baking tray.

Spread the pizza bases with a tomato based sauce and top with your favourite toppings (ham, cheese, sweetcorn, peppers, mushrooms, onions, pepperoni etc.)

Bake in a pre-heated oven at 200°C for 18-20 minutes, till the edges of the crust are golden brown.

coriander pesto

- 2 handfuls fresh leaf coriander
- 2 cloves fresh garlic
- 60g pine nuts
- 60g freshly grated Parmesan
- 100-125ml olive oil
- freshly ground black pepper

Mix the coriander, garlic, pine nuts and oil in a blender, a food processor, or a large mortar and pestle. Transfer to a bowl, and stir in the Parmesan.

Season with freshly ground black pepper, and serve as a dip, as a topping for soup, or tossed through warm pasta.

horseradish and apple sauce

- 1 sharp flavoured apple, peeled and grated
- 125ml double cream
- 3 tbsp horseradish relish
- 1 tsp paprika
- freshly ground black pepper

Beat/whisk the cream till soft peaks form, then fold in the apple, horseradish, and paprika.

Season with the pepper, and serve with beef or sausages.

black olive and anchovy tapenade/sauce

- 125g pitted black olives, drained
- 30g anchovy fillets, drained
- 1½ tbsp capers, drained
- 50-75ml olive oil
- 1 tbsp brandy (optional)
- freshly ground black pepper

Mix the olives, capers, and anchovies in a blender, a food processor, or a large mortar and pestle. Transfer to a bowl, and stir in enough oil to form a paste. This is a tapenade.

For a sauce or dip, stir in more oil to get the consistency you want. Spread on toast, or toss through warm pasta. Try it with sun-dried tomatoes instead of capers.

wheelie bin symbol

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol mustn't be disposed of with unsorted municipal waste, but recovered, reused, or recycled.



service

If you ring Customer Service, please have the **Model No.** to hand, as we won't be able to help you without it. It's on the rating plate (usually underneath the product).

The product isn't user-serviceable. If it's not working, read the instructions, check the batteries and replace them if necessary. If it's still not working, consult your retailer.

If that doesn't solve the problem – ring Customer Service – they may be able to offer technical advice.

If they advise you to return the product to us, pack it carefully, include a note with your name, address, day phone number, and what's wrong. If under guarantee, say where and when purchased, and include proof of purchase (till receipt). Send it to:

Customer Service

Salton Europe Ltd

Failsworth

Manchester

M35 0HS

email: service@saltoneurope.com

telephone: 0845 658 9700 (local rate number)

guarantee

Defects affecting product functionality appearing within one year of purchase will be corrected by replacement or repair provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. Documentation, packaging, and product specifications may change without notice.

online

www.russellhobbs.co.uk for more products